



MODELS: GWH09MA-K3DNA2E

**GWH12MB-K3DNA2E** 

GWH09MA-K3DNA3E

**GWH12MB-K3DNA3E** 

GWH09MA-K3DNA4E

**GWH12MB-K3DNA4E** 

GWH09MA-K3DNA5E

**GWH12MB-K3DNA5E** 

GWH09MA-K3DNA7E

**GWH12MB-K3DNA7E** 

**GWH12MB-K3DNA8E** 

GWH09MA-K3DNB3E

**GWH12MB-K3DNB3E** 

GWH09MA-K3DNC1E

GWH12MB-K3DNC9E

(Refrigerant R410A)

# **Table of Contents**

S	ummary and Features	1
1.	. Safety Precautions	3
2.	. Specifications	4
	2.1 Unit Specifications	4
	2.2 Operation Characteristic Curve	
	2.3 Capacity Variation Ratio According to Temperature	
	2.4 Noise Criteria Curve Tables for Both Models	9
	2.5 Operation Data	10
3.	. Construction Views	11
	3.1 Indoor Unit	11
	3.2 Outdoor Unit	
4.	. Refrigerant System Diagram	13
5.	. Schematic Diagram	14
	5.1 Electrical Wiring	14
	5.2 Printed Circuit Board	16
6.	. Function and Control	19
	6.1 Remote Control Operations	19
	6.2 Description of Each Control Operation	22
7.	. Installation Manual	27
	7.1 Notices for Installation	27
	7.2 Installation Drawing	
	7.3 Install Indoor Unit	
	7.4 Install Outdoor Unit	
	7.5 Check after Installation and Operation Test	
	7.6 Installation and Maintenance of Healthy Filter	33


8. Exploded Views and Parts List	34
8.1 Indoor Unit	34
8.2 Outdoor Unit	45
9. Troubleshooting	49
9.1 Malfunction Analysis	49
9.2 Flashing LED of Indoor/Outdoor Unit and Primary Judgement	53
9.3 How to Check Simply the Main Part	56
10. Removal Procedure	67
10.1 Removal Procedure of Indoor Unit	67
10.2 Removal Procedure of Outdoor Unit(09K)	71
10.3 Removal Procedure of Outdoor Unit(12K)	75

# **Summary and Features**

**Indoor Unit** 


GWH09MA-K3DNA2E/I GWH09MA-K3DNA3E/I GWH12MB-K3DNA2E/I GWH12MB-K3DNA3E/I(CB171N0270) GWH12MB-K3DNA3E/I(CB171N0271) GWH09MA-K3DNA4E/I GWH09MA-K3DNA5E/I GWH12MB-K3DNA4E/I GWH12MB-K3DNA5E/I 0 0 0 0 GWH09MA-K3DNA7E/I GWH09MA-K3DNB3E/I GWH12MB-K3DNA7E/I GWH12MB-K3DNB3E/I GWH12MB-K3DNA8E/I GWH12MB-K3DNC9E/I ----

#### GWH09MA-K3DNC1E/I




#### **Outdoor Unit**

GWH09MA-K3DNA4E/O



## GWH12MB-K3DNA4E/O



#### **Remote Controller**

YB1FA



# 1. Safety Precautions

Installing, starting up, and servicing air conditioner can be hazardous due to system pressure, electrical components, and equipment location, etc.

Only trained, qualified installers and service personnel are allowed to install, start-up, and service this equipment. Untrained personnel can perform basic maintenance functions such as cleaning coils. All other operations should be performed by trained service personnel.

When handling the equipment, observe precautions in the manual and on tags, stickers, and labels attached to the equipment. Follow all safety codes. Wear safety glasses and work gloves. Keep quenching cloth and fire extinguisher nearby when brazing.

Read the instructions thoroughly and follow all warnings or cautions in literature and attached to the unit. Consult local building codes and current editions of national as well as local electrical codes.

Recognize the following safety information:

Warning Incorrect handling could result in personal injury or death.



Caution Incorrect handling may result in minor injury, or damage to product or property.



All electric work must be performed by a licensed technician according to local regulations and the instructions given in this manual.

- •Before installing, modifying, or servicing system, main electrical disconnect switch must be in the OFF position. There may be more than 1 disconnect switch. Lock out and tag switch with a suitable warning label.
- Never supply power to the unit unless all wiring and tubing are completed, reconnected and checked.
- •This system adopts highly dangerous electrical voltage. Incorrect connection or inadequate grounding can cause personal injury or death. Stick to the wiring diagram and all the instructions when wiring.
- Have the unit adequately grounded in accordance with local electrical codes.
- Have all wiring connected tightly. Loose connection may lead to overheating and a possible fire hazard.

All installation or repair work shall be performed by your dealer or a specialized subcontractor as there is the risk of fire, electric shock, explosion or injury.

- •Make sure the outdoor unit is installed on a stable, level surface with no accumulation of snow, leaves, or trash beside.
- •Make sure the ceiling/wall is strong enough to bear the weight of the unit.
- •Make sure the noise of the outdoor unit does not disturb neighbors.
- •Follow all the installation instructions to minimize the risk of damage from earthquakes, typhoons or strong winds.
- Avoid contact between refrigerant and fire as it generates poisonous gas.
- Apply specified refrigerant only. Never have it mixed with any other refrigerant. Never have air remain in the refrigerant line as it may lead to rupture and other hazards.
- •Make sure no refrigerant gas is leaking out when installation is completed.
- •Should there be refrigerant leakage, the density of refrigerant in the air shall in no way exceed its limited value, or it may lead to explosion.
- •Keep your fingers and clothing away from any moving
- •Clear the site after installation. Make sure no foreign objects are left in the unit.
- •Always ensure effective grounding for the unit.



- •Never install the unit in a place where a combustible gas might leak, or it may lead to fire or explosion.
- •Make a proper provision against noise when the unit is installed at a telecommunication center or hospital.
- Provide an electric leak breaker when it is installed in a watery place.
- Never wash the unit with water.
- Handle unit transportation with care. The unit should not be carried by only one person if it is more than 20kg.
- •Never touch the heat exchanger fins with bare hands.
- •Never touch the compressor or refrigerant piping without wearing glove.
- •Do not have the unit operate without air filter.
- •Should any emergency occur, stop the unit and disconnect the power immediately.
- Properly insulate any tubing running inside the room to prevent the water from damaging the wall.

# 2. Specifications

# 2.1 Unit Specifications

Parameter	Parameter		Value
arameter		Unit	1.GWH09MA-K3DNC1E 2.GWH09MA-K3DNA4E
			3.GWH09MA-K3DNA3E 4.GWH09MA-K3DNA7E
Model			5.GWH09MA-K3DNB3E 6.GWH09MA-K3DNA5E
			7.GWH09MA-K3DNA2E
			1.CB139001600 2.CB16100200 3.CB17100260
Product Co	de		4.CB17200210 5.CB16300260 6.CB16200210 7.CB181002400
_	Rated Voltage	V ~	220-240
Power	Rated Frequency	Hz	50
Supply	Phases		1
Power Supp	ply Mode		Indoor
	pacity (Min $\sim$ Max)	W	2500(350 ~ 3000)
	pacity (Min $\sim$ Max)	W	2800(748 ~ 3500)
	wer Input (Min $\sim$ Max)	W	733(100 ~ 1150)
	wer Input (Min $\sim$ Max)	W	838(200 ~ 1430)
	wer Current	A	3.26
	wer Current	A	3.65
Rated Input		W	1430
Rated Curre		A	6.35
	lume(SH/H/M/L/SL)	m³/h	500/450/380/300/-
Dehumidify	· , , , , , , , , , , , , , , , , , , ,	L/h	0.8
EER	ing voidine	W/W	3.41
COP		W/W	3.34
SEER		W/W	1.04
HSPF		W/W	
Application Area		m <sup>2</sup>	12-18
Application	Area T	III	1.GWH09MA-K3DNC1E/I 2.GWH09MA-K3DNA4E/I
			3.GWH09MA-K3DNA3E/I 4.GWH09MA-K3DNA7E/I
	Model of Indoor Unit		5.GWH09MA-K3DNB3E/I 6.GWH09MA-K3DNA5E/I
			7.GWH09MA-K3DNA2E/I
			1.CB139N01600 2.CB161N0200 3.CB171N0260
	Indoor Unit Product Code		4.CB172N0210 5.CB163N0260 6.CB162N0210 7.CB181N02400
	Fan Type		Cross-flow
	Diameter Length(DXL)	mm	Ф85X596
	Fan Motor Cooling Speed (SH/H/M/L/SL)	r/min	1260/1050/920/730/-
	Fan Motor Heating Speed (SH/H/M/L/SL)	r/min	1320/1200/1100/950/-
	Output of Fan Motor	W	10
	Fan Motor RLA	Α	0.1
	Fan Motor Capacitor	μF	1.0
	Input of Heater	W	1
Indoor Unit	Evaporator Form		Aluminum Fin-copper Tube
	Pipe Diameter	mm	Ф7
	Row-fin Gap	mm	2-1.5
	Coil Length (LXDXW)	mm	581X25.4X264
	Swing Motor Model	<u> </u>	MP24AA
	Output of Swing Motor	W	2
	Fuse	A	3.15
	Sound Pressure Level (SH/H/M/L/SL)	dB (A)	40/37/35/32/-
	Sound Power Level (SH/H/M/L/SL)	dB (A)	50/47/45/42/-
	Dimension (WXHXD)	mm	790X265X170
	Dimension of Carton Box (LXWXH)	mm	870X355X248
	Dimension of Package (LXWXH)	mm	873X358X263
	Net Weight	kg	10
	Gross Weight	kg	13
	2.000 Holgin	ו ייש	10

Outdoor Unit Product Code		GWH09MA-K3DNA4E/O
		CB161W0200
Compressor Manufacturer/Trademark		GREE ELECTRIC APPLIANCES INC OF ZHUHAI LONGSHAN PRECISION MACHINERY MANUFACTURING AFFILATE/GREE
Compressor Model		QXA-A086zC190
Compressor Oil		FVC68D
Compressor Type		Rotary
L.R.A.	Α	12
Compressor RLA	Α	3.1
Compressor Power Input	W	850
Overload Protector		INT11L-6233
Throttling Method		Capillary
~	°C	16 ~ 30
·	°C	18 ~ 43
	°C	-7 ∼ 24
Condenser Form		Aluminum Fin-copper Tube
	mm	Φ7
·	mm	2-1.4
		695X38.1X506
<u> </u>		830±30
·		30
		0.3
		2.5
·		1600
	,	Axial-flow
	mm	Ф400
		Automatic Defrosting
		T1
		IP24
	MPa	3.8
		4.0
for the Suction Side	мРа	1.2
Sound Pressure Level (H/M/L)	dB (A)	50/-/-
Sound Power Level (H/M/L)		60/-/-
Dimension (WXHXD)	mm	776X540X320
Dimension of Carton Box (LXWXH)	mm	848X360X580
Dimension of Package (LXWXH)	mm	851X363X595
Net Weight	kg	32
Gross Weight	kg	36
Refrigerant		R410A
Refrigerant Charge	kg	0.85
Length	m	7.5
Gas Additional Charge		20
	mm	Ф6
	mm	Ф9.52
Max Distance Height	m	10
		20
	Compressor Model Compressor Oil Compressor TypeR.A. Compressor Power Input Diverload Protector Throttling Method Operation Temp Ambient Temp (Cooling) Ambient Temp (Heating) Condenser Form Pipe Diameter Rows-fin Gap Coil Length (LXDXW) Fan Motor Speed Output of Fan Motor Fan Motor RLA Fan Motor Capacitor Air Flow Volume of Outdoor Unit Fan Diameter Defrosting Method Climate Type Solation Moisture Protection Permissible Excessive Operating Pressure or the Discharge Side Permissible Excessive Operating Pressure or the Suction Side Sound Pressure Level (H/M/L) Dimension (WXHXD) Dimension of Carton Box (LXWXH) Dimension of Package (LXWXH) Net Weight Gross Weight Refrigerant Refrigerant Charge Outer Diameter Gas Pipe Outer Diameter Gas Pipe	Compressor Model Compressor Oil Compressor TypeR.A. A Compressor RLA A Compressor Power Input Diverload Protector Throttling Method Operation Temp °C Ambient Temp (Cooling) °C Condenser Form Oipe Diameter Rows-fin Gap mm Coil Length (LXDXW) mm Fan Motor Speed rpm Output of Fan Motor Fan Motor Capacitor µF Fan Motor Capacitor µF Fan Type Fan Diameter mm Oefrosting Method Climate Type Solation Moisture Protection Permissible Excessive Operating Pressure or the Discharge Side Permissible Excessive Operating Pressure or the Suction Side Sound Pressure Level (H/M/L) dB (A) Dimension (WXHXD) mm Dimension of Carton Box (LXWXH) mm Dimension of Package (LXWXH) mm Dimension of Package (LXWXH) mm Net Weight Refrigerant Refrigerant Charge g/m Outer Diameter Liquid Pipe mm Duter Diameter Gas Pipe  Diameter Diameter Gas Pipe Diameter Dameter Gas Pipe Diameter Diameter Gas Pipe  Diameter Diameter Gas Pipe Diameter Diameter Gas Pipe  Diameter Diameter Gas Pipe Diameter Diameter Gas Pipe  Diameter Diameter Diameter Gas Pipe  Di

The above data is subject to change without notice. Please refer to the nameplate of the unit.

Parameter		Unit	Value
- Graniciel		Jill	1.GWH12MB-K3DNA3E 2.GWH12MB-K3DNA3E
			3.GWH12MB-K3DNA3E 2.GWH12MB-K3DNA3E 3.GWH12MB-K3DNA5E
Model			5.GWH12MB-K3DNA7E 6.GWH12MB-K3DNB3E
liviodei			7.GWH12MB-K3DNA2E 8.GWH12MB-K3DNA8E
			9.GWH12MB-K3DNA6E
			1.CB17100270 2.CB17100271 3.CB16100210
Product Code			
Product Code			4.CB16200220 5.CB17200220 6.CB16300270
	Rated Voltage		7.CB181000200 8.CB173002300 9.CB145000300
Power		V ~	220-240
Supply	Rated Frequency	Hz	50
	Phases		1
Power Sup			Indoor
Cooling Ca	pacity (Min $\sim$ Max)	W	$3500(950 \sim 4000)$
Heating Ca	pacity (Min $\sim$ Max)	W	$3850(880 \sim 4300)$
Cooling Po	wer Input (Min $\sim$ Max)	W	1025(350 ~ 1250)
Heating Po	wer Input (Min $\sim$ Max)	W	1150(340 ~ 1360)
	wer Current	А	4.34
	wer Current	A	4.79
Rated Input		W	1480
Rated Curr		A	6.56
		m³/h	6.36
	lume(SH/H/M/L/SL)		
Dehumidify	ing Volume	L/h	1.2
EER		W/W	3.41
COP		W/W	3.35
SEER		W/W	1
HSPF	HSPF		
Application	Area	m <sup>2</sup>	16-24
			1.GWH12MB-K3DNA3E/I 2.GWH12MB-K3DNA3E/I
			3.GWH12MB-K3DNA4E/I 4.GWH12MB-K3DNA5E/I
	Model of Indoor Unit		5.GWH12MB-K3DNA7E/I 6.GWH12MB-K3DNB3E/I
			7.GWH12MB-K3DNA2E/I 8.GWH12MB-K3DNA8E/I
			9.GWH12MB-K3DNC9E/I
			1.CB171N0270 2.CB171N0271 3.CB161N0210
	Indoor Unit Product Code		4.CB162N0220 5.CB172N0220 6.CB163N0270
			7.CB181N00200 8.CB173N02300 9.CB145N00300
	Fan Type		Cross-flow
	Diameter Length(DXL)	mm	Ф92Х645
	Fan Motor Cooling Speed (SH/H/M/L/SL)	r/min	1290/1070/900/690/-
	Fan Motor Heating Speed (SH/H/M/L/SL)	r/min	1280/1050/950/880/-
	Output of Fan Motor	W	20
	Fan Motor RLA		-
		A	0.10
Indoor	Fan Motor Capacitor	μF	1.0
Unit	Input of Heater	W	
	Evaporator Form		Aluminum Fin-copper Tube
	Pipe Diameter	mm	Ф7
	Row-fin Gap	mm	2-1.4
	Coil Length (LXDXW)	mm	690X24.8X266.7
	Swing Motor Model		MP24AA
	Output of Swing Motor	W	2
	Fuse	A	3.15
	Sound Pressure Level (SH/H/M/L/SL)	dB (A)	42/39/36/33/-
	Sound Power Level (SH/H/M/L/SL)	dB (A)	52/49/46/43/-
	` '	` ′	
	Dimension (WXHXD)	mm	845X275X180
	Dimension of Carton Box (LXWXH)	mm	915X355X255
	Dimension of Package (LXWXH)	mm	918X370X258
	Net Weight	kg	11
	Gross Weight	kg	14
	·		


	Model of Outdoor Unit		GWH12MB-K3DNA4E/O
	Outdoor Unit Product Code		CB161W0210
	Compressor Manufacturer/Trademark		PANASONIC WANBAO COMPERSSOR (GUANGZHOU) CO.,LTD/ PANASONIC
	Compressor Model		5RS102ZJA21
	Compressor Oil		FV50S
	Compressor Type		Rotary
	L.R.A.	Α	25
	Compressor RLA	Α	4.47
	Compressor Power Input	W	985
	Overload Protector		1NT11L-5270 L115-15
	Throttling Method		Capillary
	Operation Temp	°C	16 ~ 30
	Ambient Temp (Cooling)	°C	18 ~ 43
	Ambient Temp (Heating)	°C	-7 ∼ 24
	Condenser Form		Aluminum Fin-copper Tube
	Pipe Diameter	mm	Ф7.94
	Rows-fin Gap	mm	2-1.4
	Coil Length (LXDXW)	mm	870X38X580
	Fan Motor Speed	rpm	900
	Output of Fan Motor	W	30
Outdoor	Fan Motor RLA	A	0.15
Unit	Fan Motor Capacitor	μF	-
	Air Flow Volume of Outdoor Unit		1800
	Fan Type	m³/h	Axial-flow
	Fan Diameter	mm	Φ400
	Defrosting Method		Automatic Defrosting
	Climate Type		T1
	Isolation		i
	Moisture Protection		IP24
	Permissible Excessive Operating Pressure		
	for the Discharge Side	MPa	3.8
	Permissible Excessive Operating Pressure		
	for the Suction Side	MPa	1.2
	Sound Pressure Level (H/M/L)	dB (A)	52/-/-
	Sound Power Level (H/M/L)	dB (A)	62/-/-
	Dimension (WXHXD)	mm	848X540X320
	Dimension of Carton Box (LXWXH)	mm	878X360X580
	Dimension of Package (LXWXH)	mm	881X363X595
	Net Weight	kg	36
	Gross Weight	kg	41
	Refrigerant		R410A
	Refrigerant Charge	kg	1.12
	Length	m	7.5
	Gas Additional Charge	g/m	20
Connection	Outer Diameter Liquid Pipe	mm	Ф6
Pipe	Outer Diameter Gas Pipe	mm	Ф9.52
	Max Distance Height	m	10
			I The state of the

The above data is subject to change without notice. Please refer to the nameplate of the unit.


## 2.2 Operation Characteristic Curve

#### 09K Unit

#### Cooling




#### Heating




#### 12K Unit


#### Cooling




#### Heating





## 2.3 Capacity Variation Ratio According to Temperature





## 2.4 Noise Criteria Curve Tables for Both Models





## 2.5 Operation Data

#### Cooling

Temperature c	ondition (°C)	Model name	Standard pressure	Heat exchanger pipe temp		Indoor fan	Outdoor fan	Compressor
Indoor	Outdoor		P (MPa)	T1 (°C)	T2 (°C)	mode	mode(rpm)	revolution (rps)
27/19	35/24	09K	0.8 ~ 1.1	12 to 15	36 to 40	Super High	830±30	54
21/19	35/24	12K	0.0~1.1	11 to 14	38 to 41	Super High	900	60

#### Heating

Temperature c	ondition (°C)	Model name	Standard pressure	Heat exchanger pipe temp		Indoor fan	Outdoor fan	Compressor
Indoor	Outdoor		P (MPa)	T1 (°C)	T2 (°C)	mode	mode(rpm)	revolution (rps)
20/-	7/6	09K	2.8 ~ 3.2	36 to 40	2 to 5	Super High	830±30	62
20/-	776	12K	2.0 ~ 3.2	38 to 41	2 to 5	Super High	900	66

T1: Outlet and inlet pipe temperature of evaporator

T2: Outlet and inlet pipe temperature of condenser

P: Pressure of air pipe used for connecting outdoor and indoor units NOTES :


(1) Measure surface temperature of heat exchanger pipe around center of heat exchanger path U bent.


(Thermistor themometer)


(2) Connecting piping condition :7.5m


# 3. Construction Views

## 3.1 Indoor Unit











#### Unit:mm


Model	W	Н	D	Q	R	S
09K	790	265	170	36	605	149
12K	845	275	180	130	542	173


## 3.2 Outdoor Unit

## (1)GWH09MA-K3DNA4E/O













## (2)GWH12MB-K3DNA4E/O










Unit:mm

# 4. Refrigerant System Diagram



Refrigerant pipe diameter

Liquid: 1/4" (6mm) Gas: 3/8" (9.52mm)

# 5. Schematic Diagram

## **5.1 Electrical Wiring**

#### Electrical Data(Meaning of marks)


#### •Indoor Unit

Symbol	Color Symbol	Symbol	Color Symbol
BU	BLUE	BN	BROWN
YE	YELLOW	BK	BLACK
RD	RED	Symbol	Part Name
YEGN	YELLOW GREEN	=	PROTECTIVE EARTH

#### Outdoor Unit


Symbol	Parts Name	Symbol	Color Symbol
L	REACTOR	WH	WHITE
AP2	PRINTED CIRCUIT BOARD	YE	YELLOW
CN2/4V/OFAN	CONNECTOR	RD	RED
OVERLOAD PROTECTOR	OVERLOAD	BN	BROWN
COMP	COMPRESSOR	BU	BLUE
	PROTECTIVE EARTH	ВК	BLACK
/	1	YEGN	YELLOW GREEN

#### •Indoor Unit




#### Outdoor Unit

#### (1)GWH09MA-K3DNA4E/O



#### (2)GWH12MB-K3DNA4E/O




These circuit diagrams are subject to change without notice, please refer to the one supplied with the unit.

## **5.2 Printed Circuit Board**


## (1)Indoor Unit

## •TOP VIEW



1	Interface of neutral wire
2	Transformer input
3	Interface of PG motor
4	Auto button
5	Feedback from PG motor
6	Up&down swing
7	Jump cap
8	Room temperature sensor
9	Pipe temperature sensor
10	Display interface of DISP- 1, DISP-2
11	Protective tube
12	Communication interface


#### •BOTTOM VIEW



## (2)Outdoor Unit


## **GWH09MA-K3DNA4E/O**

## •TOP VIEW




1 Needle base of temperature sensor 2 Memory core 3 Needle base of overload temperature sensor 4 Electronic expansion valve 5 Communication interface 6 Neutral wire(communication circuit) 7 Neutral wire (output of filtering board) 8 Live wire (output of filtering board) 9 Interface of 4-way valve 10 Interface of fan 11 Earthing wire (filtering board) 12 Input of induction 13 Output of induction		
sensor  Memory core  Needle base of overload temperature sensor  Electronic expansion valve  Communication interface  Neutral wire (communication circuit)  Neutral wire (output of filtering board)  Live wire (output of filtering board)  Interface of 4-way valve  Interface of fan  Earthing wire (filtering board)  Input of induction  Output of induction	1	1
3 Needle base of overload temperature sensor 4 Electronic expansion valve 5 Communication interface 6 Neutral wire(communication circuit) 7 Neutral wire (output of filtering board) 8 Live wire (output of filtering board) 9 Interface of 4-way valve 10 Interface of fan 11 Earthing wire (filtering board) 12 Input of induction 13 Output of induction		sensor
temperature sensor  Electronic expansion valve  Communication interface  Neutral wire(communication circuit)  Neutral wire (output of filtering board)  Live wire (output of filtering board)  Interface of 4-way valve  Interface of fan  Earthing wire (filtering board)  Input of induction  Output of induction	2	Memory core
temperature sensor  4 Electronic expansion valve  5 Communication interface  6 Neutral wire(communication circuit)  7 Neutral wire (output of filtering board)  8 Live wire (output of filtering board)  9 Interface of 4-way valve  10 Interface of fan  11 Earthing wire (filtering board)  12 Input of induction  13 Output of induction	3	Needle base of overload
5 Communication interface 6 Neutral wire(communication circuit) 7 Neutral wire (output of filtering board) 8 Live wire (output of filtering board) 9 Interface of 4-way valve 10 Interface of fan 11 Earthing wire (filtering board) 12 Input of induction 13 Output of induction		temperature sensor
6 Neutral wire(communication circuit) 7 Neutral wire (output of filtering board) 8 Live wire (output of filtering board) 9 Interface of 4-way valve 10 Interface of fan 11 Earthing wire (filtering board) 12 Input of induction 13 Output of induction	4	Electronic expansion valve
circuit)  7 Neutral wire (output of filtering board)  8 Live wire (output of filtering board)  9 Interface of 4-way valve  10 Interface of fan  11 Earthing wire (filtering board)  12 Input of induction  13 Output of induction	5	Communication interface
circuit)  7 Neutral wire (output of filtering board)  8 Live wire (output of filtering board)  9 Interface of 4-way valve  10 Interface of fan  11 Earthing wire (filtering board)  12 Input of induction  13 Output of induction	6	Neutral wire(communication
board)  8 Live wire (output of filtering board)  9 Interface of 4-way valve  10 Interface of fan  11 Earthing wire (filtering board)  12 Input of induction  13 Output of induction	0	circuit)
Board)  Live wire (output of filtering board)  Interface of 4-way valve  Interface of fan  Earthing wire (filtering board)  Input of induction  Output of induction	7	Neutral wire (output of filtering
board)  9 Interface of 4-way valve  10 Interface of fan  11 Earthing wire (filtering board)  12 Input of induction  13 Output of induction	'	board)
9 Interface of 4-way valve 10 Interface of fan 11 Earthing wire (filtering board) 12 Input of induction 13 Output of induction	8	Live wire (output of filtering
<ul> <li>10 Interface of fan</li> <li>11 Earthing wire (filtering board)</li> <li>12 Input of induction</li> <li>13 Output of induction</li> </ul>		board)
<ul><li>11 Earthing wire (filtering board)</li><li>12 Input of induction</li><li>13 Output of induction</li></ul>	9	Interface of 4-way valve
12 Input of induction 13 Output of induction	10	Interface of fan
13 Output of induction	11	Earthing wire (filtering board)
	12	Input of induction
14 Input end of compressor	13	Output of induction
	14	Input end of compressor

#### •BOTTOM VIEW




## GWH12MB-K3DNA4E/O

## •TOP VIEW



1	Input of neutral wire of power	4	Interface 1 of electric reactor	7	Neutral wire of electric heater of chassis	10	Live wire of 4-way valve	13	Temp sensor
2	Input of live wire of power	5	Interface 2 of electric reactor	8	Neutral wire of electric heater of compressor	11	Live wire of electric heater	14	U,V,W three phases of compressor
3	Communication interface	6	Interface of fan	9	Neutral wire of 4-way valve	12	Input of overload	15	Input of ground wire of power

## •BOTTOM VIEW



## 6. Function and Control

## **6.1 Remote Control Operations**



#### 1 ON/OFF

Press it to start or stop operation.

#### <sup>2</sup> MODE

Press it to select operation mode (AUTO/COOL/DRY/FAN/HEAT).

3 -

Press it to increase temperature setting.

1

Press it to decrease temperature setting.

5 FAN

Press it to set fan speed.

6

Press it to set swing angle.

7 TIMER ON

Press it to set auto-on timer.

8 TIMER OFF


Press it to set auto-off timer.

9 CLOCK

Press it to set clock.

- 10 X-FAN (X-FAN is the alternative expression of BLOW for the purpose of understanding.)
- 11 TEMP
- 12 TURBO
- 13 SLEEP
- 14 LIGHT

Press it to turn on/off the light.



#### 15 MODE icon:

If MODE button is pressed, current operation mode icon △ (AUTO), ※ (COOL), ¼ (DRY), ♣ (FAN) or ☼ (HEAT is only for heat pump models) will show.

16 SLEEP icon:

igcdot is displayed by pressing the SLEEP button. Press this button again to clear the display.

17 TEMP icon:

Pressing TEMP button, ☐ (set temperature), ⓓ (indoor ambient temperature), ⓓ (outdoor ambient temperature) and blank is displayed circularly.

18 Up & down swing icon:

🔌 is displayed when pressing the up & down swing button. Press this button again to clear the display.

19 LIGHT icon:

is displayed by pressing the LIGHT button. Press LIGHT button again to clear the display.

20 LOCK icon:

is displayed by pressing "+" and "-" buttons simultaneously. Press them again to clear the display.

21 SET TIME display:

After pressing TIMER button, ON or OFF will blink. This area will show the set time.

22 TURBO icon:

Is displayed when pressing the TURBO button. Press this button again to clear the display.

23 DIGITAL display:

This area will show the set temperature. In SAVE mode, "SE" will be displayed. During defrosting operation, "H1" will be displayed.

24 X-FAN icon:

🕏 is displayed when pressing the X-FAN button. Press this button again to clear the display.

25 FAN SPEED display:

Press FAN button to select the desired fan speed setting(AUTO Low-Med-High). Your selection will be displayed in the LCD windows, except the AUTO fan speed.

#### 1 ON/OFF:

Press this button to turn on the unit. Press this button again to turn off the unit.

2 MODE:

Each time you press this button, a mode is selected in a sequence that goes from AUTO, COOL, DRY, FAN, and HEAT \*, as the following:

AUTO ▶COOL ▶DRY▶FAN ▶ HEAT\*

\*Note: Only for models with heating function.

After energization, AUTO mode is defaulted. In AUTO mode, the set temperature will not be displayed on the LCD, and the unit will automatically select the suitable operation mode in accordance with the room temperature to make indoor room comfortable.

3 +:

Press this button to increase set temperature. Hold it down for above 2 seconds to rapidly increase set temperature. In AUTO mode, set temperature is not adjustable.

4 -:

Press this button to decrease set temperature. Hold it down for above . 2 seconds to rapidly decrease set temperature. In AUTO mode, set temperature is not adjustable.

5 FAN:

This button is used for setting fan speed in the sequence that goes from AUTO, - , - , - to then back to Auto.



Low speed ▲ Medium speed ▲ High speed

6

Press this button to set up & down swing angle, which circularly changes as below:

This remote controller is universal. If any command  $\Rightarrow$  or  $\Rightarrow$  is sent out, the unit will carry out the command as  $\Rightarrow$ 

indicates the guide louver swings as:

#### 7 TIMER ON:

Press this button to initiate the auto-ON timer. To cancel the auto-timer program, simply press this button again. After pressing this button, (a) disappears and "ON" blinks . 0 0:00 is displayed for ON time setting. Within 5 seconds, press + or - button to adjust the time value. Every press of either button changes the time setting by 1 minute. Holding down either button rapidly changes the time setting by 1 minute and then 10 minutes. Within 5 seconds after setting, press TIMER ON button to confirm.

#### **8 TIMER OFF:**

Press this button to initiate the auto-off timer. To cancel the auto-timer program, simply press the button again. TIMER OFF setting is the same as TIMER ON.

#### 9 CLOCK:

Pressing CLOCK button, (2) blinks. Within 5 seconds, pressing + or - button adjusts the present time. Holding down either button above 2 seconds increases or decreases the time by 1 minute every 0.5 second and then by 10 minutes every 0.5 second. During blinking after setting, press CLOCK button again to confirm the setting, and then (2) will be constantly displayed.

#### 10 X-FAN:

Pressing X -FAN button in COOL or DRY mode, the icon % is displayed and the indoor fan will continue operation for 10 minutes in order to dry the indoor unit even though you have turned off the unit.

After energization, X-FAN OFF is defaulted. X-FAN is not available in AUTO, FAN or HEAT mode.

#### 11 TEMP:

Press this button, could select displaying the indoor setting temperature or indoor ambient temperature. When the indoor unit firstly power on it will display the setting temperature, if the temperature's displaying status is changed from other status to " (a) ", displays the ambient temperature, 5s later or within 5s, it receives other remote control signal that will return to display the setting temperature. If the users haven't set up the temperature displaying status, that will display the setting temperature.

#### 12 TURBO:

Press this button to activate / deactivate the Turbo function which enables the unit to reach the preset temperature in the shortest time. In COOL mode, the unit will blow strong cooling air at super high fan speed. In HEAT mode, the unit will blow strong heating air at super high fan speed.

#### 13 SLEEP:

Press this button to go into the SLEEP operation mode. Press it again to cancel this function. This function is available in COOL, HEAT (Only for models with heating function) or DRY mode to maintain the most comfortable temperature for you.

#### 14 LIGHT:

Press LIGHT button to turn on the display's light and press this button again to turn off the display's light. If the light is turned on ,  $\circ$  is displayed. If the light is tunned off,  $\circ$  disappears.

- 15 Combination of "+" and "-" buttons: About lock
  - Press "+" and "-" buttons simultaneously to lock or unlock the keypad. If the remote controller is locked, is displayed. In this case, pressing any button, blinks three times.
- 16 Combination of "MODE" and "-" buttons: About switch between Fahrenheit and Centigrade At unit OFF, press "MODE" and "-" buttons simultaneously to switch between and .

#### Replacement of Batteries

1.Remove the battery cover plate from the rear of the remote controller.

(As shown in the figure)


- 2. Take out the old batteries.
- 3.Insert two new AAA1.5V dry batteries, and pay attention to the polarity.
- 4. Reinstall the battery cover plate.

#### Notes:

•When replacing the batteries, do not use old or different types of batteries.

Otherwise, it may cause malfunction.

- •If the remote controller will not be used for a long time,
- please remove batteries to prevent batteries from leaking.
- •The operation should be performed in its receiving range.
- •It should be kept 1m away from the TV set or stereo sound sets.
- •If the remote controller does not operate normally, please take the batteries out and reinsert them after 30 seconds. If it still can't operate properly, replace the batteries.



## 6.2 Description of Each Control Operation

#### 1. Temperature Parameters

- ◆ Indoor preset temperature (Tpreset)
- ♦ Indoor ambient temperature (Tamb.)

#### 2. Basic Functions

Once energized, in no case should the compressor be restarted within less than 3 minutes. In the situation that memory function is available, for the first energization, if the compressor is at stop before de-energization, the compressor will be started without a 3-minute lag; if the compressor is in operation before de-energization, the compressor will be started with a 3-minute lag; and once started, the compressor will not be stopped within 6 minutes regardless of changes in room temperature;

#### (1) Cooling Mode

#### 1 Working conditions and process of cooling

When Tamb.≥Tpreset, the unit will enter cooling operation, in which case the indoor fan, the outdoor fan and the compressor will work and the indoor fan will run at preset speed.


When Tamb.=Tpreset-2°C, the compressor will run in 15Hz for continuous 15 minutes; if Tamb.=Tpreset-2°C is not changed after that, the compressor will stop to run;

When Tamb.≤Tpreset-3℃, the compressor will stop to run, the outdoor fan motor will stop to run after 30 seconds and the indoor fan motor will run at set fan speed;

When Tpreset-2  $^{\circ}$ C < Tamb. < Tpreset, the unit will keep the previous running status.

Under this mode, the four-way valve will be de-energized and temperature can be set within a range from 16 to 30°C.

If the compressor is shut down for some reason, the indoor fan and the swing device will operate at original state.



#### 2 Protection

#### **◆** Antifreeze protection

Under cooling and dehumidifying mode, 6 minutes after the compressor is started:

If T evap≤2°C, the compressor will operate at reduced frequency.

If T evap≤-1°Cis detected for durative 3 minutes, the compressor will stop, and after 30 seconds, the outdoor fan will stop; and under cooling mode, the indoor fan and the swing motor will remain at the original state.

If T evap. ≥10°Cand the compressor has remained at OFF for at least 3 minutes, the compressor will resume its original operation state.

#### ◆ Total current up and frequency down protection

If Itotal≤6, frequency rise will be allowed; if Itotal≥7, frequency rise will not be allowed; ifItotal≥8, the compressor will run at reduced frequency; and if Itotal≥9, the compressor will stop and the outdoor fan will stop with a time lag of 30s.

#### (2) Dehumidifying Mode

#### ① Working conditions and process of dehumidifying

If Tamb>Tpreset, the unit will enter cooling and dehumidifying mode, in which case the compressor and the outdoor fan will operate and the indoor fan will run at low speed.

If Tpreset -2°C≤Tamb≤Tpreset, the compressor remains at its original operation state.

If Tamb.< Tpreset -2°C, the compressor will stop, the outdoor fan will stop with a time lag of 30s, and the indoor fan will operate at low speed.

#### 2 Protection

Protection is the same as that under the cooling mode.

#### (3) Heating Mode

#### ① Working conditions and process of heating

If Tamb.≤Tpreset +2°C, the unit enters heating mode, in which case the four-way valve, the compressor and the outdoor fan will operate simultaneously, and the indoor fan will run at preset speed in the condition of preset cold air prevention.

If T amb.≥Tpreset +5°C, the compressor will stop, the outdoor fan will stop with a time lag of 30s, and the indoor fan will stop after 60-second blow at low speed

If Tpreset +2°C<T amb.< Tpreset +5°C, the unit will maintain its original operating status.

Under this mode, the four-way valve is energized and temperature can be set within a range of 16 - 30°C. The operating symbol, the heating symbol and preset temperature are revealed on the display.

#### 2 Condition and process of defrost

When duration of successive heating operation is more than 45 minutes, or accumulated heating time more than 90 minutes, and one of the following conditions is reached, the unit will enter the defrost mode after 3 minutes.

- (1). T outdoor ambient > 5°C, T outdoor tube≤-2°C;
- (2)  $-2^{\circ}C \le T$  outdoor ambient  $< 5^{\circ}C$ , T outdoor tube  $\le -6^{\circ}C$ ;
- (3) -5°C≤T outdoor ambient < -2°C, T outdoor tube≤-8°C;
- (4)-10°C≤T outdoor ambient<-5°C, T outdoor tube-T compensatory≤(T outdoor ambient-3°C)
- (5)T outdoor ambient<-10°C, T outdoor tube-T compensatory ≤ (T outdoor ambient-3°C)

(after energizing, T compensatory=0°C during the first defrosting; if it is not the first defrosting, T compensatory is confirmed by T outdoor tube of quitting last defrosting: a. when T outdoor tube>2°C, T compensatory=0°C; b. when T outdoor tube  $\leq$ 2°C, T compensatory=3°C)

At that time, the indoor fan stops and the compressor stops, and after 30 seconds the outer fan will stop, and then after 30 seconds, the four-way valve will stop. After 30 seconds, the compressor is initiated for raising the frequency to defrost frequency.

When the compressor has operated under defrost mode for 7.5 minutes, or T outdoor ambient  $\geq 10^{\circ}$ C, the compressor will be converted to 46Hz operation. After 30 seconds, the compressor will stop. And after another 30 seconds, the four-way valve will be opened, and after 60 seconds, the compressor and the outer fan will be started, the indoor fan will run under preset cold air prevention conditions, and H1 will be displayed at temperature display area on the display panel. Defrost frequency is 85Hz.

#### ③ Protection

#### Cold air prevention

The unit is started under heating mode (the compressor is ON):

- ① In the case of T indoor amb. <24°C: if T tube≤40°C and the indoor fan is at stop state, the indoor fan will begin to run at low speed with a time lag of 2 minutes. Within 2 minutes, if T tube>40°C, the indoor fan also will run at low speed; and after 1-minute operation at low speed, the indoor fan will be converted to operation at preset speed. Within 1-minute low speed operation or 2-minute non-operation, if T tube>42°C, the fan will run at present speed.
- ② In the case of T indoor amb. ≥24°C: if T tube≤42°C, the indoor fan will run at low speed, and after one minute, the indoor fan will be converted to preset speed. Within one-minute low speed operation, if T tube>42°C, the indoor fan will be converted to preset speed.

Note: T indoor amb. indicated in ① and ② refers to, under initially heating mode, the indoor ambient temperature before the command to start the compressor is performed according to the program, or after the unit is withdrawn from defrost, the indoor ambient temperature before the defrost symbol is cleared.

#### ◆ Total current up and frequency down protection

If the total current Itotal≤6, frequency rise will be allowed; if Itotal≥7, frequency rise will not be allowed; if Itotal≥8, the compressor will run at reduced frequency; and if Itotal≥9, the compressor will stop and the outdoor fan will stop with a time lag of 30s.

#### (4) Fan Mode

Under the mode, the indoor fan will run at preset speed and the compressor, the outdoor fan, the four-way valve and the electric heater will stop.

Under the mode, temperature can be set within a range of 16 - 30°C.

#### (5) AUTO Mode

#### ① Working conditions and process of AUTO mode

- a. When T ambient ≥26°C, the unit will operate in Cool mode. The set temperature is 25°C.
- b. When T ambient ≤22°C, the heat pump unit will operate in Heat mode., set temperature be 20°C; the cooling only unit will operate in Fan mode, set temperature be 25°C.
- c. When  $23^{\circ}C \le T$  ambient  $\le 25^{\circ}C$ , the unit will operate in the previous state. If it is energized for the first time, it will operate in Fan mode.
- d. Under auto mode, if it's cooling mode, operation frequency is same as that under cooling mode; if it's heating mode, operation frequency is same as that under heating mode.

#### 2 Protection

- a. In cooling operation, protection is the same as that under the cooling mode;
- b. In heating operation, protection is the same as that under the heating mode;
- c. When ambient temperature changes, operation mode will be converted preferentially. Once started, the compressor will remain unchanged for at least 6 minutes.

#### (6) Common Protection Functions and Fault Display under COOL, HEAT, DRY and AUTO Modes

#### 1 Overload protection

T tube: measured temperature of outdoor heat exchanger under cooling mode; and measured temperature of indoor heat exchanger under heating mode.

#### 1) Cooling overload

- a. If T tube≤52°C, the unit will return to its original operation state.
- b. If T tube≥55°C, frequency rise is not allowed.
- c. If T tube≥58°C, the compressor will run at reduced frequency.
- d. If T tube≥62°C, the compressor will stop and the indoor fan will run at preset speed.

#### 2) Heating overload

- a. If T tube≤50°C, the unit will return to its original operation state.
- b. If T tube≥53°C, frequency rise is not allowed.
- c. If T tube≥56°C, the compressor will run at reduced frequency.
- d. If T tube≥60°C, the compressor will stop and the indoor fan will blow residue heat and then stop.

#### 2 Exhaust temperature protection of compressor

If exhaust temperature ≥98°C, frequency is not allowed to rise.

If exhaust temperature ≥103°C, the compressor will run at reduced frequency.

If exhaust temperature ≥110°C, the compressor will stop.

If exhaust temperature ≤90°Cand the compressor has stayed at stop for at least 3 minutes, the compressor will resume its operation.

#### **③ Communication fault**

If the unit fails to receive correct signals for durative 3 minutes, communication fault can be justified and the whole system will stop.

#### **4** Module protection

Under module protection mode, the compressor will stop. When the compressor remains at stop for at least 3 minutes, the compressor will resume its operation. If module protection occurs six times in succession, the compressor will not be started again.

#### **(5) Overload protection**

If temperature sensed by the overload sensor is over 115°C, the compressor will stop and the outdoor fan will stop with a time lag of 30 seconds. If temperature is below 95°C, the overload protection will be relieved°C.

#### **(6)** DC bus voltage protection

If voltage on the DC bus is below 150V or over 420V, the compressor will stop and the outdoor fan will stop with a time lag of 30 seconds. When voltage on the DC bus returns to its normal value and the compressor has stayed at stop for at least 3 minutes, the compressor will resume its operation.

#### 7 Faults of temperature sensors

Designation of sensors	Faults
Indoor ambient temperature	The sensor is detected to be open-circuited or short-circuited for successive 30 seconds
Indoor tube temperature	The sensor is detected to be open-circuited or short-circuited for successive 30 seconds
Outdoor ambient temperature	The sensor is detected to be open-circuited or short-circuited for successive 30 seconds
Outdoor tube temperature	The sensor is detected to be open-circuited or short-circuited for successive 30 seconds, and no detection is performed within 10 minutes after defrost begins.
Exhaust	After the compressor has operated for 3 minutes, the sensor is detected to be open-circuited or short-circuited for successive 30 seconds.
Overload	After the compressor has operated for 3 minutes, the sensor is detected to be open-circuited or short-circuited for successive 30 seconds.

#### 3. Other Controls

#### (1) ON/OFF

Press the remote button ON/OFF: the on-off state will be changed once each time you press the button.

#### (2) Mode Selection

Press the remote button MODE, then select and show in the following ways: AUTO, COOL, DRY, FAN, HEAT, AUTO.

#### (3) Temperature Setting Option Button

Each time you press the remote button TEMP+ or TEMP-, the setting temperature will be up or down by 1°C. Regulating Range: 16~30°C, the button is useless under the AUTO mode.

#### (4) Time Switch

You should start and stop the machine according to the setting time by remote control.

#### (5) SLEEP State Control

- a. When the air conditioner is under the mode of COOL, DRY, and the SLEEP mode has been set well, after the SLEEP state keeps about 1 hour, the pre-setting T will raise 1°C, and it will raise 1°C again after 2 hours, so it raise 2°C in 2 hours, then it will run on at the setting temperature and wind speed.
- b. When the air conditioner is under the mode of HEAT, and the Timer has been set well, after the SLEEP state keeps about 1 hour, the pre-setting T will reduce 1°C, and it will reduce 1°C again after 2 hours, so it reduce 2°C in 2 hours, then it will run on at the setting temperature and wind speed.
- c. The setting temperature keeps the same under the FAN mode and AUTO mode.

#### (6) Indoor Fan Control

The Indoor Fan can be set as HIGH, MED, LOW by remote control, and the Indoor Fan will be respectively run at high, medium, low speed. It will also be set as AUTO, and the Indoor Fan is as the followings at the automatic wind speed.

Cooling mode: T ring  $\geq$  T setting + 2°C, high speed; T setting - 2°C<T ring<T setting + 2°C, medium speed; T ring $\leq$  T setting - 2°C, low speed.

Sending wind mode: T ring> T setting +  $4^{\circ}$ C, high speed; T setting +  $2^{\circ}$ C $\leq$ T ring $\leq$ T setting +  $4^{\circ}$ C, medium speed; T ring $\leq$ T setting +  $2^{\circ}$ C, low speed.

Moisture removal mode: force to be set as the low speed

Heating mode: T ring $\leq$  T setting + 1°C, high speed; T setting +1°C<T ring<T setting + 5°C, medium speed; T ring $\geq$ T setting + 2°C, low speed.

#### (7) Buzzer Control


The buzzer will send a "Di" sound when the air conditioner is powered up or received the information sent by the remote control or there is a button input, the single tube cooler doesn't receive the remote control ON signal under the mode of heating mode.


#### (8) Auto buttor

If the controller is on, it will stop by pressing the button, and if the controller is off, it will be automatic running state by pressing the button, swing on and light on, and the main unit will run based on the remote control if there is remote control order.

#### (9) Up-and-Down Swinging Control

When power on, the up-and-down motor will firstly move the air deflector to counter-clockwise, close the air outlet. After starting the machine, if you don't set the swinging function, heating mode and auto-heating mode, the up-and-down air deflector will move to D clockwise; under other modes, the up-and-down air deflector will move to L1. If you set the swinging function when you start the machine, then the wind blade will swing between L and D. The air deflector has 7 swinging states: Location L, Location A, Location B, Location D, Location D, to Location D, stop at any location between L-D (the included angle between L~D is the same). The air deflector will be closed at 0 Location, and the swinging is effectual only on condition that setting the swinging order and the inner fan is running. The indoor fan and compressor may get the power when air deflector is on the default location.





#### (10) Display

#### ① Operation pattern and mode pattern display

All the display patterns will display for a time when the power on, the operation indication pattern will display in red under standby status. When the machine is start by remote control, the indication pattern will light and display the current operation mode (the mode light includes: Cooling, heating and dehumidify). If you close the light key, all the display patterns will close.

#### 2 Double-8 display

According to the different setting of remote control, the nixie light may display the current temperature (the temperature scope is from 16°C to 30°C) and indoor ambient temperature. The heating and air supply temperature will display 25°C under auto-mode, the temperature will display 18°C under the heating mode, and the temperature will display H1 under the defrosting mode.(If you set the fahrenheit temperature display, the nixie light will display according to fahrenheit temperature)

#### (11) Protection function and failure display

E2: Freeze-proofing protection E4: Exhausting protection E5: Overcurrent protection

E6: Communication failure H4: Overload protection

F1: Indoor ambient sensor start and short circuit (continuously measured failure in 30S)

F2: Indoor evaporator sensor start and short circuit (continuously measured failure in 30S)

F3: Outdoor ambient sensor start and short circuit (continuously measured failure in 30S)

F4: Outdoor condenser sensor start and short circuit (continuously measured failure in 30S, and don't measure within 10 minutes after defrosted)

F5: Outdoor exhausting sensor start and short circuit (continuously measured failure in 30S after the compressor operated 3 minutes)

H3: Overload protection of compressor H5: Module protection
PH: High-voltage protection PL: Low-voltage protection
P1: Nominal cooling and heating P2: Maximum cooling and heating
P3: Medium cooling and heating P0: Minimum cooling and heating

#### (12) Drying Function

You may start or stop the drying function under the modes of cooling and dehumidify at the starting status (The modes of automatism, heating and air supply do not have drying function). When you start the drying function, after stop the machine by pressing the switch button, you should keep running the inner fans for 10 minutes under low air damper (The swing will operate as the former status within 10 minutes, and other load is stopped), then stop the entire machine; When you stop the drying function, press the switch button will stop the machine directly. When you start the drying function, operating the drying button will stop the inner fans and close the guide louver.

#### (13) Memory function when interrupting the power supply

Memory content: mode, swing function, light, set temperature and wind speed. After interrupted the power supply, the machine will start when recovering the power according to the memory content automatically. If the last remote control command has not set the timed function, the system will remember the last remote control command and operate according it. If the last remote control command has set timed function and the power supply is interrupted before the timed time, the system will remember the timed function of the last remote control command, the timed time will recounted form power on. If the last remote control command has set timed function, the time is out and the system is start or stop according to the set time when the power supply is interrupted, the system will remember the operation status before the power supply was interrupted, and do not carry out timed action; The timed clock will not remembered.

## 7. Installation Manual

#### 7.1 Notices for Installation

# Caution

- 1. The unit should be installed only by authorized service center according to local or government regulations and in compliance with this manual.
- 2.Before installing, please contact with local authorized maintenance center. If the unit is not installed by the authorized service center, the malfunction may not be solved due to incovenient contact between the user and the service personnel.
- 3. When removing the unit to the other place, please firstly contact with the local authorized service center.
- 4. Warning: Before obtaining access to terminals, all supply circuits must be disconnected.
- 5. For appliances with type Y attachment, the instructions shall contain the substance of the following. If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.
- 6. The appliance must be positioned so that the plug is accessible.
- 7.The temperature of refrigerant line will be high; please keep the interconnection cable away from the copper tube.
- 8. The instructions shall state the substance of the following:

This appliance is not intended for use by persons(including children)with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.

Children should be supervised to ensure that they do not play with the appliance.

#### 7.1.1 Installation Site Instructions

Proper installation site is vital for correct and efficient operation of the unit. Avoid the following sites where:

- •strong heat sources, vapours, flammable gas or volatile liquids are emitted.
- •high-frequency electro-magnetic waves are generated by radio equipment, welders and medical equipment.
- •salt-laden air prevails (such as close to coastal areas).
- •the air is contaminated with industrial vapours and oils.
- •the air contains sulphures gas such as in hot spring zones.
- •corrosion or poor air quality exists.

#### 7.1.2 Installation Site of Indoor Unit

- 1. The air inlet and outlet should be away from the obstructions. Ensure the air can be blown through the whole room.
- 2.Select a site where the condensate can be easily drained out, and where it is easily connected to outdoor unit.
- 3. Select a place where it is out of reach of children.
- 4.Select a place where the wall is strong enough to withstand the full weight and vibration of the unit.
- 5.Be sure to leave enough space to allow access for routine maintenance. The installation site should be 250cm or more above the floor.
- 6. Select a place about 1m or more away from TV set or any other electric appliance.
- 7. Select a place where the filter can be easily taken out.
- 8.Make sure that the indoor unit is installed in accordance with installation dimension instructions.
- 9.Do not use the unit in the laundry or by swimming pool etc.

#### 7.1.3 Installation Site of Outdoor Unit

- 1. Select a site where noise and outflow air emitted by the unit will not annoy neighbors.
- 2.S elect a site where there is sufficient ventilation.
- 3. Select a site where there is no obstruction blocking the inlet and outlet.
- 4. The site should be able to withstand the full weight and vibration.
- 5. Select a dry place, but do not expose the unit to direct sunlight or strong wind.
- 6.Make sure that the outdoor unit is installed in accordance with the installation instructions, and is convenient for maintenance and repair.
- 7. The height difference between indoor and outdoor units is within 10 m, and the length of the connecting tubing does not exceed 20 m.
- 8. Select a place where it is out of reach of children.
- 9. Select a place where the unit does not have negative impact on pedestrians or on the city.

#### 7.1.4 Safety Precautions for Electric Appliances

- 1.A dedicated power supply circuit should be used in accordance with local electrical safety regulations.
- 2.Don't drag the power cord with excessive force.
- 3.The unit should be reliably earthed and connected to an exclusive earth device by the professionals.
- 4. The air switch must have the functions of magnetic tripping and heat tripping to prevent short circuit and overload.
- 5. The minimum distance between the unit and combustive surface is 1.5m.
- 6. The appliance shall be installed in accordance with national wiring regulations.
- 7.An all-pole disconnection switch with a contact separation of at least 3mm in all poles should be connected in fixed wiring.

#### Note:

- •Make sure the live wire, neutral wire and earth wire in the family power socket are properly connected. There should be reliable circuit in the diagram.
- •Inadequate or incorrect electrical connections may cause electric shock or fire.


#### 7.1.5 Earthing Requirements

- **1**. Air conditioner is type I electric appliance. Please ensure that the unit is reliably earthed.
- 2. The yellow-green wire in air conditioner is the earthing wire which can not be used

for other purposes. Improper earthing may cause electric shock.

- 3. The earth resistance should accord to the national criterion.
- 4.The power must have reliable earthing terminal. Please do not connect the earthing wire with the following:
- ① Water pipe ② Gas pipe ③ Contamination pipe
- 4 Other place that professional personnel consider is unreliable
- 5. The model and rated values of fuses should accord with the silk print on fuse cover or related PCB.


## 7.2 Installation Drawing




#### 7.3 Install Indoor Unit

#### 7.3.1 Installation of Mounting Plate


- 1. Mounting plate should be installed horizontally. As the water tray's outlet for the indoor unit is two-way type, during installation, the indoor unit should slightly slant to water tray's outlet for smooth drainage of condensate.
- 2.Fix the mounting plate on the wall with screws.
- 3.Be sure that the mounting plate has been fixed firmly enough to withstand about 60 kg. Meanwhile, the weight should be evenly shared by each screw.





#### 7.3.2 Drill Piping Hole

- 1.Slant the piping hole ( $\Phi$ 55) on the wall slightly downward to the outdoor side.
- 2.Insert the piping-hole sleeve into the hole to prevent the connection piping and wiring from being damaged when passing through the hole.



#### 7.3.3 Installation of Drain Hose


- 1. Connect the drain hose to the outlet pipe of the indoor unit. Bind the joint with rubber belt.
- 2.Put the drain hose into insulating tube.
- 3. Wrap the insulating tube with wide rubber belt to prevent the shift of insulating tube. Slant the drain hose downward slightly for smooth drainage of condensate.

Note: The insulating tube should be connected reliably with the sleeve outside the outlet pipe. The drain hose should be slanted downward slightly, without distortion, bulge or fluctuation. Do not put the outlet in the water.

# outlet pipe of indoor unit rubber belt outlet pipe of indoor unit rubber belt insulating tube rubber belt outlet pipe of indoor unit outlet pipe of indoor u

#### 7.3.4 Connecting Indoor and Outdoor Electric Wires

- 1. Open the front panel.
- 2.Remove the wiring cover .Connect and fix the power connection cord to the terminal board. As shown in Fig 2.
- 3. Make the power connection cord pass through the hole at the back of indoor unit.
- 4. Reinstall the cord anchorage and wiring cover.
- 5. Reinstall the front panel.



Flooded


#### NOTE:

#### All wires between indoor and outdoor units must be connected by the qualified electric contractor.

- Electric wires must be connected correctly. Improper connection may cause malfunction.
- Tighten the terminal screws securely.
- After tightening the screws, pull the wire slightly to confirm whether it's firm or not.
- Make sure that the electric connections are earthed properly to prevent electric shock.
- Make sure that all wiring connections are secure and the cover plates are reinstalled properly. Poor installation may cause fire or electric shock.

#### 7.3.5 Installation of Indoor Unit

- •The piping can be output from right, right rear, left or left rear.
- 1. When routing the piping and wiring from the left or right side of indoor unit, cut off the tailings from the chassis when necessary(As shown in Fig.3)
- (1) Cut off tailing 1 when routing the wiring only;
- (2) Cut off tailing 1 and tailing 2 when routing both the wiring and piping.
- 2. Take out the piping from body case; wrap the piping, power cords, drain hose with the tape and then make them pass through the piping hole. (As shown in Fig.4)
- 3. Hang the mounting slots of the indoor unit on the upper hooks of the mounting plate and check if it is firm enough. (As shown in Fig.5)
- 4. The installation site should be 250cm or more above the floor.




#### 7.3.6 Installation of Connection Pipe

- 1. Align the center of the pipe flare with the related valve.
- 2.Screw in the flare nut by hand and then tighten the nut with spanner and torque wrench by referring to the following:

Hex nut diameter	Tightening torque (N·m)		
Ф6	15 $\sim$ 20		
Ф9.52	31 $\sim$ 35		
Ф12	50 $\sim$ 55		
Ф16	$60\sim65$		
Ф19	<b>70</b> ~ <b>75</b>		

NOTE: Connect the connection pipe to indoor unit at first and then to outdoor unit. Handle piping bending with care. Do not damage the connection pipe. Ensure that the joint nut is tightened firmly, otherwise, it may cause leakage.



#### 7.4 Install Outdoor Unit

#### 7.4.1 Electric Wiring


- 1.Remove the handle on the outdoor unit right side plate.
- 2. Take off wire cord anchorage. Connect and fix the power connection cord to the terminal board. Wiring should fit that of indoor unit.
- 3.Fix the power connection cord with wire clamps and then connect the corresponding connector.
- 4. Confirm if the wire has been fixed properly.
- 5.Reinstall the handle.

#### NOTE:

- •Incorrect wiring may cause malfunction of spare part.
- •After the wire has been fixed, ensure there is free

space between the connection and fixing places on the lead wire.

Schematic diagram being reference only, please refer to real product for authentic information.



#### 7.4.2 Air Purging and Leakage Test

1. Connect charging hose of manifold valve to charge end of low pressure valve (both high/low pressure valves must be tightly shut).

Connect joint of charging hose to vacuum pump.

- 3. Fully open the handle of Lo manifold valve.
- 4. Open the vacuum pump for vacuumization. At the beginning, slightly loosen joint nut of low pressure valve to check if there is air coming inside (If noise of vacuum pump has been changed, the reading of multimeter is 0). Then tighten the nut.

5. Keep vacuuming for more than 15 mins and make


sure the reading of multi-meter is -1.0X10<sup>5</sup> pa(-76cmHg).


- 6. Fully open high/low pressure valves.
- 7. Remove charging hose from charging end of low pressure valve.
- 8. Tighten lid of low pressure valve. (As shown in Fig.6)




During heating operation, the condensate and defrosting water should be drained out reliably through the drain hose. Install the outdoor drain connector in a Φ25 hole on the base plate and attach the drain hose to the connector so that the waste water formed in the outdoor unit can be drained out .The hole diameter 25 must be plugged.

Whether to plug other holes will be determined by the dealers according to actual conditions.







## 7.5 Check after Installation and Operation Test

#### 7.5.1 Check after Installation

Items to be checked	Possible malfunction
Has it been fixed firmly?	The unit may drop, shake or emit noise.
Have you done the refrigerant leakage test?	It may cause insufficient cooling(heating) capacity
ls heat insulation sufficient?	It may cause condensation and dripping.
ls water drainage satisfactory?	It may cause condensation and dripping.
Is the voltage in accordance with the rated voltage marked on the nameplate?	It may cause electric malfunctionor damage the product.
securely?	It may cause electric malfunction or damage the part.
Has the unit been connected to a secure earth connection?	It may cause electrical leakage.
Is the power cord specified?	It may cause electric malfunctionor damage the part.
Are the inlet and outlet openings blocked?	It may cause insufficient cooling(heating) capacity.
Is the length of connection pipes and refrigerant capacity been recorded?	The refrigerant capacity is not accurate.

#### 7.5.2 Operation Test

- 1.Before Operation Test
- (1)Do not switch on power before installation is finished completely.
- (2)Electric wiring must be connected correctly and securely.
- (3)Cut-off valves of the connection pipes should be opened.
- (4)All the impurities such as scraps and thrums must be cleared from the unit.
- 2. Operation Test Method
- (1)Switch on power and press "ON/OFF"button on the remote controller to start operation.
- (2)Press MODE button to select the COOL, HEAT (Not available for cooling only unit), FAN to check whether the operation is normal or not.

## 7.6 Installation and Maintenance of Healthy Filter

#### 7.6.1 Installation of Healthy Filter

1.Lift up the front panel from its two ends, as shown by the arrow direction, and then remove the air filter. (As shown in fig. a)




Fig. b
Air filter
Healthy filter

Healthy filter

2.Attach the healthy filter onto the air filter. (as shown in fig. b)

3.Install the air filter properly along the arrow direction in Fig.c, and then close the panel .

#### 7.6.2 Cleaning and Maintenance

Remove the healthy filter and reinstall it after cleaning according to the installation instruction. Don't use brush or hard things to clean the filter. After cleaning, be sure to dry it in the shade.

#### 7.6.3 Service Life


The general serive life for the healthy filter is about one year under normal condition. As for silver ion filter, it is invalid when its surface becomes black (green).

•This supplementary instruction is provided for reference to the unit with healthy filter. If the graphics provided herein is different from the actual product, please refer to the atual product. The quantity of healthy filters is based on the actual delivery.

# 8. Exploded Views and Parts List

### 8.1 Indoor Unit


(1)GWH09MA-K3DNA2E/I、GWH09MA-K3DNA3E/I、GWH09MA-K3DNA4E/I、GWH09MA-K3DNA5E/I GWH09MA-K3DNA7E/I、GWH09MA-K3DNB3E/I



	Description	Part Code						
NO.	Description	GWH09MA-K3DNA2E/I	GWH09MA-K3DNA3E/I	GWH09MA-K3DNA4E/I	Qty			
	Product Code	CB181N02400	CB171N0260	CB161N0200				
1	Front Panel Assy	20192265	20012241	2001217601	1			
2	Filter Sub-Assy	11122081	11122081	11122081	2			
3	Screw Cover	24252016	24252016	24252016	3			
4	Electric Box Cover2	20122075	20122075	20122075	1			
5	Front Case	20012120	20012120	20012120	1			
6	Axile Bush	10542008	10542008	10542008	1			
7	Guide Louver	10512111	10512111	10512111	1			
8	Air Louver 2	10512114	10512114	10512114	1			
9	Air Louver 1	10512113	10512113	10512113	1			
10	Helicoid Tongue	26112162	26112162	26112162	1			
11	Crank	10582070	10582070	10582070	1			
12	Rear Case assy	2220210101	2220210101	2220210101	1			
13	Cross Flow Fan	10352018	10352018	10352018	1			
14	O-Gasket of Cross Fan Bearing	76512203	76512203	76512203	1			
15	O-Gasket sub-assy of Bearing	76512051	76512051	76512051	1			
16	Fan Bearing	76512210	76512210	76512210	1			
17	Ring of Bearing	26152022	26152022	26152022	1			
18	Remote Controller	30510041	30510041	30510041	1			
19	Drainage Hose	0523001406	0523001406	0523001406	1			
20	Wall Mounting Frame	01252015	01252015	01252015	1			
21	Evaporator Assy	01002760	01002760	01002760	1			
22	Evaporator Support	24212090	24212090	24212090	1			
23	Connecting Cable	400205236	400205236	400205236	1			
24	Power Cord	40020491	40020491	40020491	1			
25	Front Panel	200121428	200121218	20012151S	1			
26	Ambient Temperature Sensor	390000451	390000451	390000451	1			
27	Tube Sensor	390000591G	390000591G	390000591G	1			
28	Main Board	30138476	30138476	30138476	1			
29	Terminal Board	42011233	42011233	42011233	<u>·</u> 1			
30	Electric Box	2011208201	2011208201	2011208201	<u>·</u> 1			
31	Transformer	43110283	43110283	43110283	<u>'</u> 1			
32	Electric Box Assy	2020206206	2020212813	2020206204	<u>'</u> 1			
33	Display Board	30565056	30565007	30565012	<u>'</u> 1			
34	Axile Bush	10542704	10542704	10542704	<u>'</u> 1			
35	Step Motor	1521212901	1521212901	1521212901	1			
	Rubber Plug (Water Tray)							
36	- 77	76712012	76712012	76712012	1			
37	Motor Press Plate	26112160	26112160	26112160	1			
38	Fan Motor	15012115	15012115	15012115	1			
39	Pipe Clamp	26112164	26112164	26112164	1			
40	Jumper	4202300102	4202300102	4202300102	1			
41	Capacitor CBB61	33010002	33010002	33010002	1			
42	Shield Cover of Electric Box Sub-assy	01592073	01592073	01592073	1			
43	Shield Cover of Electric Box	01412036	01412036	01412036	1			
44	Electric Box Cover1	20122103	20122103	20122103	1			


	L	Part Code						
NO.	Description	GWH09MA-K3DNA5E/I	GWH09MA-K3DNB3E/I	Qty				
	Product Code	CB162N0210	CB172N0210	CB163N0260				
1	Front Panel Assy	20012287	2001222901	2001227802	1			
2	Filter Sub-Assy	11122081	11122081	11122081	2			
3	Screw Cover	24252016	24252016	24252016	3			
4	Electric Box Cover2	20122075	20122075	20122075	1			
5	Front Case	20012120	20012120	20012120	1			
6	Axile Bush	10542008	10542008	10542008	1			
7	Guide Louver	10512111	10512111	10512111	1			
8	Air Louver 2	10512114	10512114	10512114	1			
9	Air Louver 1	10512113	10512113	10512113	1			
10	Helicoid Tongue	26112162	26112162	26112162	1			
11	Crank	10582070	10582070	10582070	1			
12	Rear Case assy	2220210101	2220210101	2220210101	1			
13	Cross Flow Fan	10352018	10352018	10352018	1			
14	O-Gasket of Cross Fan Bearing	76512203	76512203	76512203	1			
15	O-Gasket sub-assy of Bearing	76512051	76512051	76512051	1			
16	Fan Bearing	76512210	76512210	76512210	1			
17	Ring of Bearing	26152022	26152022	26152022	1			
18	Remote Controller	30510041	30510041	30510041	1			
19	Drainage Hose	0523001406	0523001406	0523001406	1			
20	Wall Mounting Frame	01252015	01252015	01252015	1			
21	Evaporator Assy	01002760	01002760	01002760	1			
22	Evaporator Support	24212090	24212090	24212090	1			
23	Connecting Cable	400205236	400205236	400205236	1			
24	Power Cord	40020491	40020491	40020491	1			
25	Front Panel	20012196S	2001219101S	20012201S	1			
26	Ambient Temperature Sensor	390000451	390000451	390000451	1			
27	Tube Sensor	390000591G	390000591G	390000591G	1			
28	Main Board	30138476	30138476	30138476	1			
29	Terminal Board	42011233	42011233	42011233	1			
30	Electric Box	2011208201	2011208201	2011208201	1			
31	Transformer	43110283	43110283	43110283	1			
32	Electric Box Assy	20202547	2020255402	20202554	1			
33	Display Board	30565073	30565030	30565037	1			
34	Axile Bush	10542704	10542704	10542704	1			
35	Step Motor	1521212901	1521212901	1521212901	1			
36	Rubber Plug (Water Tray)	76712012	76712012	76712012	1			
37	Motor Press Plate	26112160	26112160	26112160	1			
38	Fan Motor	15012115	15012115	15012115	1			
39	Pipe Clamp	26112164	26112164	26112164	1			
40	Jumper	4202300102	4202300102	4202300102	1			
41	Capacitor CBB61	33010002	33010002	33010002	1			
42	Shield Cover of Electric Box Sub-assy	01592073	01592073	01592073	1			
43	Shield Cover of Electric Box	01412036	01412036	01412036	1			
44	Electric Box Cover1	20122103	20122103	20122103	1			

### (2)GWH09MA-K3DNC1E/I



	Decembrican	Part Code	
NO.	Description	GWH09MA-K3DNC1E/I	Qty
	Product Code	CB139N01600	
1	Front Panel Assy	20012463	1
2	Filter Sub-Assy	11122081	2
3	Screw Cover	24252016	3
4	Electric Box Cover2	20122075	1
5	Front Case	20012179	1
6	Guide Louver	10512111	1
7	Helicoid Tongue	26112162	1
8	Air Louver 2	10512114	1
9	Air Louver 1	10512113	1
10	Drainage Hose	0523001406	1
11	Axile Bush	10542704	1
12	Crank	10582070	1
13	Step Motor	1521212901	1
14	Rear Case assy	2220210101	1
15	Pipe Clamp	26112164	1
16	Fan Motor	15012115	1
17	Wall Mounting Frame	01252015	1
18	Motor Press Plate	26112160	1
19	Cross Flow Fan	10352018	1
20	Evaporator Assy	01002760	1
21	Evaporator Support	24212090	1
22	O-Gasket sub-assy of Bearing	76512051	1
23	Ring of Bearing	26152022	1
24	Rubber Plug (Water Tray)	76712012	1
25	Remote Controll Holder	27210071	1
26	Connecting Cable	400205236	1
27	Power Cord	40020491	1
28	Electric Box	2011208201	1
29	Main Board	30138476	1
30	Jumper	4202300102	1
31	Transformer	43110283	1
32	Lower Shield Sub-assy of Electric Box	01592072	1
33	Terminal Board	42011233	1
34	Electric Box Cover1	20122103	1
35	Shield Cover of Electric Box Sub-assy	01592073	1
36	Display Board	30565088	1
37	Electric Box Assy	2020206217	1
38	Axile Bush	10542008	1

(3)GWH12MB-K3DNA2E/I、GWH12MB-K3DNA3E/I、GWH12MB-K3DNA3E/I(Delonghi)、GWH12MB-K3DNA4E/I GWH12MB-K3DNA5E/I、GWH12MB-K3DNA7E/I、GWH12MB-K3DNB3E/I、GWH12MB-K3DNC9E/I




	Description	Part Code						
NO.	Description	GWH12MB-K3DNA2E/I	GWH12MB	Qty				
	Product Code	CB181N00200	CB171N0270	CB171N0271				
1	Front Panel	20012150S	20012122S	20012122S	1			
2	Filter Sub-Assy	1112220403	1112220403	1112220403	2			
3	Screw Cover	24252016	24252016	24252016	1			
4	Front Case Sub-assy	20012139	20012139	20012139	1			
5	Axile Bush	10542008	10542008	10542008	1			
6	Guide Louver	10512157	10512157	10512157	1			
7	Air Louver 2	10512155	10512155	10512155	1			
8	Helicoid Tongue	26112163	26112163	26112163	1			
9	Display Board	30565056	30565007	30565095	1			
10	Left Axile Bush	10512037	10512037	10512037	1			
11	Rear Case assy	2220210302	2220210302	2220210302	1			
12	Cross Flow Fan	10352017	10352017	10352017	1			
13	O-Gasket sub-assy of Bearing	76512051	76512051	76512051	1			
14	Ring of Bearing	26152022	26152022	26152022	1			
15	Remote Controller	30510041	30510041	30510041	1			
16	Drainage Hose	0523001401	0523001401	0523001401	1			
17	Evaporator Support	24212091	24212091	24212091	1			
18	Evaporator Assy	01002610	01002321	01002321	1			
19	Connecting Cable	400205236	400205236	400205236	1			
20	Power Cord	40020491	40020491	40020491	1			
21	Shield Cover of Electric Box Sub-assy	01592073	01592073	01592073	1			
22	Electric Box Cover2	20122075	20122075	20122075	1			
23	Jumper	4202300104	4202300104	4202300104	1			
24	Ambient Temperature Sensor	390000451	390000451	390000451	1			
25	Main Board	30138476	30138476	30138476	1			
26	Tube Sensor	390000591G	390000591G	390000591G	1			
27	Terminal Board	42011233	42011233	42011233	1			
28	Air Louver 1	10512156	10512156	10512156	1			
29	Electric Box	20112082	20112082	20112082	1			
30	Capacitor CBB61	33010002	33010002	33010002	1			
31	Transformer	43110283	43110283	43110283	1			
32	Electric Box Assy	20202612	2020212810	20202574	1			
33	Crank	10582070	10582070	10582070	1			
34	Step Motor	1521212901	1521212901	1521212901	1			
35	Rubber Plug (Water Tray)	76712012	76712012	76712012	1			
36	Fan Motor	150120874	150120874	150120874	1			
37	Motor Press Plate	26112161	26112161	26112161	1			
38	Pipe Clamp	26112164	26112164	26112164	1			
39	Wall Mounting Frame	01252021	01252021	01252021	1			
40	Electric Box Cover1	20122103	20122103	20122103	1			

	Description	Part Code						
NO.	Description	GWH12MB-K3DNA4E/I	GWH12MB-K3DNA4E/I GWH12MB-K3DNA5E/I					
	Product Code	CB161N0210	CB162N0220	CB172N0220				
1	Front Panel	20012153S	20012199S	20012189S	1			
2	Filter Sub-Assy	1112220403	1112220403	1112220403	2			
3	Screw Cover	24252016	24252016	24252016	1			
4	Front Case Sub-assy	20012139	20012139	20012139	1			
5	Axile Bush	10542008	10542008	10542008	1			
6	Guide Louver	10512157	10512157	10512157	1			
7	Air Louver 2	10512155	10512155	10512155	1			
8	Helicoid Tongue	26112163	26112163	26112163	1			
9	Display Board	30565012	30565073	30565007	1			
10	Left Axile Bush	10512037	10512037	10512037	1			
11	Rear Case assy	2220210302	2220210302	2220210302	1			
12	Cross Flow Fan	10352017	10352017	10352017	1			
13	O-Gasket sub-assy of Bearing	76512051	76512051	76512051	1			
14	Ring of Bearing	26152022	26152022	26152022	1			
15	Remote Controller	30510041	30510041	30510041	1			
16	Drainage Hose	0523001401	0523001401	0523001401	1			
17	Evaporator Support	24212091	24212091	24212091	1			
18	Evaporator Assy	01002610	01002610	01002610	1			
19	Connecting Cable	400205236	400205236	400205236	1			
20	Power Cord	40020491	40020491	40020491	1			
21	Shield Cover of Electric Box Sub-assy	01592073	01592073	01592073	1			
22	Electric Box Cover2	20122075	20122075	20122075	1			
23	Jumper	4202300104	4202300104	4202300104	1			
24	Ambient Temperature Sensor	390000451	390000451	390000451	1			
25	Main Board	30138476	30138476	30138476	1			
26	Tube Sensor	390000591G	390000591G	390000591G	1			
27	Terminal Board	42011233	42011233	42011233	1			
28	Air Louver 1	10512156	10512156	10512156	1			
29	Electric Box	20112082	20112082	20112082	1			
30	Capacitor CBB61	33010002	33010002	33010002	1			
31	Transformer	43110283	43110283	43110283	1			
32	Electric Box Assy	2020212811	20202548	2020255403	1			
33	Crank	10582070	10582070	10582070	1			
34	Step Motor	1521212901	1521212901	1521212901	1			
35	Rubber Plug (Water Tray)	76712012	76712012	76712012	1			
36	Fan Motor	150120874	150120874	150120874	1			
37	Motor Press Plate	26112161	26112161	26112161	1			
38	Pipe Clamp	26112164	26112164	26112164	1			
39	Wall Mounting Frame	01252021	01252021	01252021	1			
40	Electric Box Cover1	20122103	20122103	20122103	1			

	L	Part Code					
NO.	Description	GWH12MB-K3DNB3E/I	GWH12MB-K3DNC9E/I	Qty			
	Product Code	CB163N0270	CB145N00300	7			
1	Front Panel	20012202S	20012687S	1			
2	Filter Sub-Assy	1112220403	1112220403	2			
3	Screw Cover	24252016	24252016	1			
4	Front Case Sub-assy	2001213901	20012139	1			
5	Axile Bush	10542008	10542008	1			
6	Guide Louver	10512157	10512157	1			
7	Air Louver 2	10512155	10512155	1			
8	Helicoid Tongue	26112163	26112163	1			
9	Display Board	30565037	30565056	1			
10	Left Axile Bush	10512037	10512037	1			
11	Rear Case assy	2220210302	2220210302	1			
12	Cross Flow Fan	10352017	10352017	1			
13	O-Gasket sub-assy of Bearing	76512051	76512051	1			
14	Ring of Bearing	26152022	26152022	1			
15	Remote Controller	30510041	30510041	1			
16	Drainage Hose	0523001401	0523001401	1			
17	Evaporator Support	24212091	24212091	1			
18	Evaporator Assy	01002610	0100261002	1			
19	Connecting Cable	400205236	400205236	1			
20	Power Cord	40020491	40020491	1			
21	Shield Cover of Electric Box Sub-assy	01592073	01592073	1			
22	Electric Box Cover2	20122075	20122075	1			
23	Jumper	4202300104	4202300104	1			
24	Ambient Temperature Sensor	390000451	390000451	1			
25	Main Board	30138476	30138476	1			
26	Tube Sensor	390000591G	390000591G	1			
27	Terminal Board	42011233	42011233	1			
28	Air Louver 1	10512156	10512156	1			
29	Electric Box	20112082	20112082	1			
30	Capacitor CBB61	33010002	33010002	1			
31	Transformer	43110283	43110283	1			
32	Electric Box Assy	2020255401	2020261205	1			
33	Crank	10582070	10582070	1			
34	Step Motor	1521212901	1521212901	1			
35	Rubber Plug (Water Tray)	76712012	76712012	1			
36	Fan Motor	150120874	150120874	1			
37	Motor Press Plate	26112161	26112161	1			
38	Pipe Clamp	26112164	26112164	1			
39	Wall Mounting Frame	01252021	01252021	1			
40	Electric Box Cover1	20122103	20122103	1			


### (4)GWH12MB-K3DNA8E/I



D.	occiption.	Part Code	
NO.	escription	GWH12MB-K3DNA8E/I	Qty
Pr	roduct Code	CB173N02300	
1 Fr	ont Panel	20012200S	1
2 Fi	Iter Sub-Assy	1112220403	2
3 Sc	crew Cover	24252016	1
4 Fr	ont Case Sub-assy	2001213901	1
5 Ax	xile Bush	10542008	1
6 G	uide Louver	10512157	1
7 Ai	r Louver 2	10512155	1
8 H	elicoid Tongue	26112163	1
9 Di	splay Board	3056504301	1
10 Le	eft Axile Bush	10512037	1
11 R	ear Case assy	2220210302	1
12 Cı	ross Flow Fan	10352017	1
13 O-	-Gasket sub-assy of Bearing	76512051	1
14 Ri	ng of Bearing	26152022	1
15 R	emote Controller	305100413	1
16 Dı	rainage Hose	0523001401	1
17 E\	/aporator Support	24212091	1
18 E\	vaporator Assy	01002610	1
19 Co	onnecting Cable	400205236	1
20 Pc	ower Cord	40020491	1
21 SI	nield Cover of Electric Box Sub-assy	01592073	1
22 EI	ectric Box Cover2	20122075	1
23 Ju	imper	4202300104	1
24 Ar	mbient Temperature Sensor	390000451	1
25 M	ain Board	30138476	1
26 Tu	ube Sensor	390000591G	1
27 Te	erminal Board	42011233	1
28 Ai	r Louver 1	10512156	1
29 EI	ectric Box	20112082	1
30 Ca	apacitor CBB61	33010002	1
31 Tr	ansformer	43110283	1
32 EI	ectric Box Assy	2020261209	1
33 Cı	rank	10582070	1
34 St	ep Motor	1521212901	1
35 R	ubber Plug (Water Tray)	76712012	1
36 Fa	an Motor	150120874	1
37 M	otor Press Plate	26112161	1
38 Pi	pe Clamp	26112164	1
39 W	all Mounting Frame	01252021	1
40 EI	ectric Box Cover1	20122103	1


### 8.2 Outdoor Unit

(1)GWH09MA-K3DNA4E/O



	Description	Part Code	
NO.	Description	GWH09MA-K3DNA4E/O	Qty
	Product Code	CB161W0200	
1	Electric Box Assy	02603436	1
2	Electric Box Sub-Assy	02603381	1
3	Main Board	30138391	1
4	Reactor	43130184	1
5	Terminal Board	42011113	1
6	Wire Clamp	71010003	1
7	Front Grill	22413433	1
8	Front Panel	01533033P	1
9	Axial Flow Fan	10333004	1
10	Chassis Sub-assy	01203912P	1
11	Fan Motor	15013076	1
12	Small Handle	26233100	1
13	Top Cover Sub-Assy	01253454	1
14	Motor Support Sub-Assy	0170309701Y	1
15	Condenser Assy	01113674	1
16	Temperature Sensor	3900030804G	1
17	Rear Grill	01473009	1
18	Capillary Sub-assy	03063192	1
19	Temp Sensor Sleeving	05212423	1
20	Cut off Valve	07133082	1
21	Big Handle	26233433	1
22	Valve	07100005	1
23	Valve Support	0170308901P	1
24	Right Side Plate Sub-Assy	0130317801	1
25	4-Way Valve Assy	03123385	1
26	Clapboard Sub-Assy	01233385	1
27	Magnetic Ring	49010104	1
28	Compressor and Fittings	00103224_G	1
29	Drainage Connecter	06123401	1

### (2)GWH12MB-K3DNA4E/O





	Description	Part Code	
NO.	Description	GWH12MB-K3DNA4E/O	Qty
	Product Code	CB161W0210	
1	Front grill	22413433	1
2	Front Panel	015330124	1
3	Chassis Sub-assy	01203919P	1
4	Drainage Connecter	06123401	1
5	Compressor and fittings	00103215	1
6	Magnet Coil	4300040047	1
7	Temperature Sensor	39000310	1
8	4-way Valve	430004032	1
9	4-way Valve Assy	03123420	1
10	Right Side Plate Assy	0130200404	1
11	Valve	07100005	1
12	Valve Support	01713041	1
13	Valve	07100004	1
14	Big Handle	26233433	1
15	Capillary Sub-Assy	03063193	1
16	StrainerA	07210022	1
17	Rear Grill	01473014	1
18	Condenser Assy	01113675	1
19	Clapboard Sub-Assy	01233034	1
20	Top Cover Plate	1253443	1
21	Motor Support Sub-Assy	0170309701Y	1
22	Fan Motor	15013158	1
23	Reactor sub-assy	01403616	1
24	Reactor	43130185	1
25	Cover of Reactor box	01413029	1
26	Electric Box Assy	0140398666	1
27	Electric Box Cover Sub-Assy	0260309601	1
28	Main Board	30138659	1
29	Electric box 1	20113005	1
30	Terminal Board	42011113	1
31	Radiator	49010252	1
32	Axial Flow Fan	10333004	1


### 9. Troubleshooting


### 9.1 Malfunction Analysis

Note: When replacing the controller, be sure to insert the wire jumper into the new controller, otherwise the unit will display C5










## 9.2 Flashing LED of Indoor/Outdoor Unit and Primary Judgement

Nana of malfunction	Display of indoor unit	state of th	e lamps of outdoo	or unit PCB	Decemb
Nane of malfunction	ERROR CODE	GREEN-LED2 RED-LED3 YELLOW-LED4			Reasons
Stop for anti-freezing protection of indoor-unit	freezing F2 blink_3tim		blink-3times	refrigerant leakage、indoor unit air flow blocked up、filter duty	
Stop for exhaust protection	E4			blink-7 times	less refrigerant、capillary blocked up、 ambient temperature is abominable
Overcurrent protection	E5			blink-5 times	low voltage, ambient temperature is abominable
Stop for communication malfunction	E6	do not blink			communication line failure、main PCB failure、interfere souce、connect line wrong
Stop for compressor overload protection	Н3			blink-8 times	compressor shell over heat, lessrefrigerant, capillary blocked up
Overload protection	H4			blink-6 times	ambient temperature is abominable heat exchanger blocked up
Stop for IPMmodule protetion	H5			blink-4 times	IPM moudel over heat、low voltage、silica gel
PG motor (indoor fan motor) does not operate	H6				PG motor control terminal does not contact well; Blade does not rotate fluently due to incorrect installation; motor or control panel is damaged
Indoor ambient temperature sensor malfunction	F1				terminal connect not reliable、temperature sensor maifunction
Indoor tube temperature sensor malfunction	F2				terminal connect not reliable、temperature sensor maifunction
Outdoor ambient temperature sensor malfunction	F3		blink-6 times		terminal connect not reliable、temperature sensor maifunction
Outdoor tube temperature sensor malfunction	F4		blink-5 times		terminal connect not reliable、temperature sensor maifunction
Outdoor exhaust temperature sensor malfunction	F5		blink-7 times		terminal connect not reliable、temperature sensor maifunction
Jumper cap malfunction protection	C5				there's no jumper cap on the controller, jumper cap is not inserted properly and tightly, jumper cap is damaged, corresponding circuit on mainboard has malfunction
Indoor and outdoor units can't match with each other	LP			blink-16times	Indoor unit and outdoor units can't match with each other
PG motor(indoor fan) zero-cross detection circuit malfunction	U8				abnormal of zero-cross detection circuit of controller mainboard.
PFC overcurrent malfunction	HC			blink-14times	Overcurrent of PFC
High protection of power	L9			blink-9times	Complete unit's power is too high
High voltage protection	PH			blink-13times	DC side voltage is too high
low voltage protection	PL			blink-12times	DC side voltage is too low
Automatic defrosting	H1			blink-2 times	H1is not error code,it is noemal operation. Just heat pump has this fuction
REMARK:		fun	ction,the lamps or	n the outdoor pcb a	display pcb.maybe some type has not this ire avaiable or unit is successful, the gree lam



#### Analysis or processing of some of the malfunction display:

#### 1. Compressor discharge protection

Possible causes: shortage of refrigerant; blockage of air filter; poor ventilation or air flow short pass for condenser; the system has noncondensing gas (such as air, water etc.); blockage of capillary assy (including filter); leakage inside four-way valve causes incorrect operation; malfunction of compressor; malfunction of protection relay; malfunction of discharge sensor; outdoor temperature too high.

Processing method: refer to the malfunction analysis in the above section.

#### 2. Low voltage overcurrent protection

Possi ble cause: Sudden drop of supply voltage.

### 3. Communication malfunction

Processing method: Check if communication signal cable is connected reliably.

#### 4. Sensor open or short circuit

Processing method: Check whether sensor is normal, connected with the corre sponding position on the controller and if damage of lead wire is found.

#### 5. Compressor over load protection

Possible causes: insufficient or too much refrigrant; blockage of capillary and increase of suction temp.; improper running of compressor, burning in or stuck of bearing, damage of discharge valve; malfunction of protector.

Processing method: adjust refrigerant amount; replace the capillary; replace the compressor; use universal meter to check if the contactor of compress or is fine when it is not overheated, if not replace the protector.

#### 6. System malfunction

i.e.overload protection. When tube temperature (Check the temperature of outdoor heat exchanger when cooling and check the temperature of indoor heat exchanger when heating) is too high, protection will be activated.


Possi ble causes: Outdoor temperature is too high when cooling; insufficient outdoor air circulation; refrigerant flow malfunction. please refer to the malfunction analysis in the previous section for handling method.

### 7. IPM module protection

Processing method:Once the module malfunction happens, if it persists for a long time and can not be selfcanceled, cut off the power and turn off the unit, and then re-energize the unit again after about 10 min. After repeating the procedure for sever times, if the malfunction still exists, replace the module.

### 9.3 How to Check Simply the Main Part

- (1) Capacitor charge fault (Fault with outdoor unit) (AP1 below refers to the outdoor control panel) Main Check Points:
- •Use AC voltmeter to check if the voltage between terminal L and N on the wiring board is within 210VAC~240VAC.
- •Is the reactor (L) correctly connected? Is the connection loose or fallen? Is the reactor (L) damaged?



### (2) IPM Protection, Out-of-step Fault, Compressor Phase Overcurrent (AP1 below refers to the outdoor control panel)

Main check points:

- •Is the connection between control panel AP1 and compressor COMP secure? Loose? Is the connection in correct order?
- •Is the voltage input of the machine within normal range? (Use AC voltmeter to measure the voltage between terminal L and N on the
- •Is the compressor coil resistance normal? Is the insulation of compressor coil against the copper tube in good condition?
- •Is the working load of the machine too high? Is the radiation good?

I s the charge volume of refrigerant correct? Fault diagnosis process: Energize and switch on If the voltage between terminal L and N on wiring board XT is within 210VAC~250VAC Use AC voltmeter Check the supply to measure the voltage between terminal L and N IPM protection occurs after the machine has run for a period of time? voltage and restore it to on the wiring board XT) 210VAC~250VA Restart the unit. Before Voltage between protection occurs. use DC voltmeter to measure the voltage between the two ends of electrolytic capacitor on control panel AP1 the two ends of celectrolyl capacitor is higher than If the unit can work normally Please confirm:

1. If the indoor and outdoor heat exchangers are dirty? If hey are obstructed by other objects which affect the heat exchange of indoor and outdoor unit.

2. If the indoor and outdoor fans are working normally?

3. If the environment temperature is too high, resulting in that the system pressure is loo on igh and exceeds the permissible range?


4. If the charge volume of refrigerant is too much, resulting in that the system pressure is too 5 much conditions for the c 250y Reconnect the capacitor C2 according to Electrical Wiring Diagram. Then, Restart the unit Stop the unit and disconnect the power supply. Then, check the connection of capacitor C2 according to Electrical Wiring Diagram. The connection of capacitor C2 is loose Remove the wires on the two ends of capacitor C2. Then, use capacitance meter to measure the capacitor C2. Verify as per the Parameters Sheet. Stop the unit and disconnect the power supply. Wait 20 minutes, or use DC voltmeter to measure the voltage between the two ends of capacitor C2, until the voltage is lower than 20V If the unit can work normally Replace the capacitor C2. Then, energize If the unit can If capacitor C2 is failed? work normally and start the unit. Replace the control panel AP1 Refer to the Electrical Wiring Diagram and check if the connection between AP1 and COMP is loose and if the connection order is correct. Take corrective actions according to Technical Service Manual, and then engize and start If there is an abnormality described abo If the unit car work normally? Replace the control panel AP1 Connect the control panel AP1 and compressor COMP correctly according to the Electrical Wiring Diagram. Then, energize and start the unit. If the connection between AP1 and COMP is unsecure or the connection order is wrong? If the unit car Use ohmmeter to measure the resistance between the three terminals on compressor COMP, and compare the measurements with the compressor resistance on Service Manual. If the resistance is normal? Use ohmmeter to measure the resistance between the two terminals of compressor COMP and copper tube. Resistance higher than 500MΩ? Replace the control panel

END

# (3)High temperature and overload protection diagnosis (AP1 hereinafter refers to the control board of the outdoor unit)

Mainly detect:


- •Is outdoor ambient temperature in normal range?
- •Are the outdoor and indoor fans operating normally?
- •Is the heat dissipation environment inside and outside the unit good?



### (4) Start-up failure (following AP1 for outdoor unit control board)


Mainly detect:

- •Whether the compressor wiring is connected correct?
- •Is compressor broken?
- •Is time for compressor stopping enough?



# (5) Out of step diagnosis for the compressor (AP1 hereinafter refers to the control board of the outdoor unit) Mainly detect:


- •Is the system pressure too high?
- •Is the input voltage too low?



### (6)Overload and air exhaust malfunction diagnosis (following AP1 for outdoor unit control board)

Mainly detect:


- •Is the PMV connected well or not? Is PMV damaged?
- •Is refrigerant leaked?



# (7)Power factor correct or (PFC) fault (a fault of outdoor unit) (AP1 hereinafter refers to the control board of the outdoor unit)

Mainly detect:


•Check if the reactor (L) of the outdoor unit and the PFC capacitor are broken



### (8) Communication malfunction: (following AP1 for outdoor unit control board)

Mainly detect:

- •Is there any damage for the indoor unit mainboard communication circuit? Is communication circuit damaged?
- •Detect the indoor and outdoor units connection wire and indoor and outdoor units inside wiring is connect well or not, if is there any damage?



## **Appendix**

Appendix	1: Resistance	e T	Table of An	nbient Tempe	rature Sens	or for Indoor	aı	nd Outdoor	Units(15K)
Temp. (°C)	Resistance(kΩ)		Temp. (°C)	Resistance(kΩ)	Temp. (°C)	Resistance(kΩ)		Temp. (°C)	Resistance(kΩ)
-19	138.1		20	18.75	59	3.848		98	1.071
-18	128.6		21	17.93	60	3.711		99	1.039
-17	121.6		22	17.14	61	3.579		100	1.009
-16	115		23	16.39	62	3.454		101	0.98
-15	108.7		24	15.68	63	3.333		102	0.952
-14	102.9		25	15	64	3.217		103	0.925
-13	97.4		26	14.36	65	3.105		104	0.898
-12	92.22		27	13.74	66	2.998		105	0.873
-11	87.35		28	13.16	67	2.896		106	0.848
-10	82.75		29	12.6	68	2.797		107	0.825
-9	78.43		30	12.07	69	2.702		108	0.802
-8	74.35		31	11.57	70	2.611		109	0.779
-7	70.5		32	11.09	71	2.523		110	0.758
-6	66.88		33	10.63	72	2.439		111	0.737
-5	63.46		34	10.2	73	2.358		112	0.717
-4	60.23		35	9.779	74	2.28		113	0.697
-3	57.18		36	9.382	75	2.206		114	0.678
-2	54.31		37	9.003	76	2.133		115	0.66
-1	51.59		38	8.642	77	2.064		116	0.642
0	49.02		39	8.297	78	1.997		117	0.625
1	46.6		40	7.967	79	1.933		118	0.608
2	44.31		41	7.653	80	1.871		119	0.592
3	42.14		42	7.352	81	1.811		120	0.577
4	40.09		43	7.065	82	1.754		121	0.561
5	38.15		44	6.791	83	1.699		122	0.547
6	36.32		45	6.529	84	1.645		123	0.532
7	34.58		46	6.278	85	1.594		124	0.519
8	32.94		47	6.038	86	1.544		125	0.505
9	31.38		48	5.809	87	1.497		126	0.492
10	29.9		49	5.589	88	1.451		127	0.48
11	28.51		50	5.379	89	1.408		128	0.467
12	27.18		51	5.197	90	1.363		129	0.456
13	25.92		52	4.986	91	1.322		130	0.444
14	24.73		53	4.802	92	1.282		131	0.433
15	23.6		54	4.625	93	1.244		132	0.422
16	22.53		55	4.456	94	1.207		133	0.412
17	21.51		56	4.294	95	1.171		134	0.401
18	20.54		57	4.139	96	1.136		135	0.391
19	19.63		58	3.99	97	1.103		136	0.382

Apper	Appendix 2: Resistance Table of Outdoor and Indoor Tube Temperature Sensors(20K)									
Temp. (°C)	Resistance(kΩ)		Temp. (°C)	Resistance(kΩ)		Temp. (°C)	Resistance(kΩ)		Temp. (°C)	Resistance(kΩ)
-19	181.4		20	25.01		59	5.13		98	1.427
-18	171.4		21	23.9		60	4.948		99	1.386
-17	162.1		22	22.85		61	4.773		100	1.346
-16	153.3		23	21.85		62	4.605		101	1.307
-15	145		24	20.9		63	4.443		102	1.269
-14	137.2		25	20		64	4.289		103	1.233
-13	129.9		26	19.14		65	4.14		104	1.198
-12	123		27	18.13		66	3.998		105	1.164
-11	116.5		28	17.55		67	3.861		106	1.131
-10	110.3		29	16.8		68	3.729		107	1.099
-9	104.6		30	16.1		69	3.603		108	1.069
-8	99.13		31	15.43		70	3.481		109	1.039
-7	94		32	14.79		71	3.364		110	1.01
-6	89.17		33	14.18		72	3.252		111	0.983
-5	84.61		34	13.59		73	3.144		112	0.956
-4	80.31		35	13.04		74	3.04		113	0.93
-3	76.24		36	12.51		75	2.94		114	0.904
-2	72.41		37	12		76	2.844		115	0.88
-1	68.79		38	11.52		77	2.752		116	0.856
0	65.37		39	11.06		78	2.663		117	0.833
1	62.13		40	10.62		79	2.577		118	0.811
2	59.08		41	10.2		80	2.495		119	0.77
3	56.19		42	9.803		81	2.415		120	0.769
4	53.46		43	9.42		82	2.339		121	0.746
5	50.87		44	9.054		83	2.265		122	0.729
6	48.42		45	8.705		84	2.194		123	0.71
7	46.11		46	8.37		85	2.125		124	0.692
8	43.92		47	8.051		86	2.059		125	0.674
9	41.84		48	7.745		87	1.996		126	0.658
10	39.87		49	7.453		88	1.934		127	0.64
11	38.01		50	7.173		89	1.875		128	0.623
12	36.24		51	6.905		90	1.818		129	0.607
13	34.57		52	6.648		91	1.736		130	0.592
14	32.98		53	6.403		92	1.71		131	0.577
15	31.47		54	6.167		93	1.658		132	0.563
16	30.04		55	5.942		94	1.609		133	0.549
17	28.68		56	5.726		95	1.561		134	0.535
18	27.39		57	5.519		96	1.515		135	0.521
19	26.17		58	5.32		97	1.47		136	0.509

Appendix 3: Resistance Table of Outdoor Discharge Temperature Sensor(50K)							
Temp. (°C)	Resistance(kΩ)	Temp. (°C)	Resistance(kΩ)	Temp. (°C)	Resistance(kΩ)	Temp. (°C)	Resistance(kΩ)
-29	853.5	10	98	49	18.34	88	4.754
-28	799.8	11	93.42	50	17.65	89	4.609
-27	750	12	89.07	51	16.99	90	4.469
-26	703.8	13	84.95	52	16.36	91	4.334
-25	660.8	14	81.05	53	15.75	92	4.204
-24	620.8	15	77.35	54	15.17	93	4.079
-23	580.6	16	73.83	55	14.62	94	3.958
-22	548.9	17	70.5	56	14.09	95	3.841
-21	516.6	18	67.34	57	13.58	96	3.728
-20	486.5	19	64.33	58	13.09	97	3.619
-19	458.3	20	61.48	59	12.62	98	3.514
-18	432	21	58.77	60	12.17	99	3.413
-17	407.4	22	56.19	61	11.74	100	3.315
-16	384.5	23	53.74	62	11.32	101	3.22
-15	362.9	24	51.41	63	10.93	102	3.129
-14	342.8	25	49.19	64	10.54	103	3.04
-13	323.9	26	47.08	65	10.18	104	2.955
-12	306.2	27	45.07	66	9.827	105	2.872
-11	289.6	28	43.16	67	9.489	106	2.792
-10	274	29	41.34	68	9.165	107	2.715
-9	259.3	30	39.61	69	8.854	108	2.64
-8	245.6	31	37.96	70	8.555	109	2.568
-7	232.6	32	36.38	71	8.268	110	2.498
-6	220.5	33	34.88	72	7.991	111	2.431
-5	209	34	33.45	73	7.726	112	2.365
-4	198.3	35	32.09	74	7.47	113	2.302
-3	199.1	36	30.79	75	7.224	114	2.241
-2	178.5	37	29.54	76	6.998	115	2.182
-1	169.5	38	28.36	77	6.761	116	2.124
0	161	39	27.23	78	6.542	117	2.069
1	153	40	26.15	79	6.331	118	2.015
2	145.4	41	25.11	80	6.129	119	1.963
3	138.3	42	24.13	81	5.933	120	1.912
4	131.5	43	23.19	82	5.746	121	1.863
5	125.1	44	22.29	83	5.565	122	1.816
6	119.1	45	21.43	84	5.39	123	1.77
7	113.4	46	20.6	85	5.222	124	1.725
8	108	47	19.81	86	5.06	125	1.682
9	102.8	48	19.06	87	4.904	126	1.64

Note: The information above is for reference only.

### 10. Removal Procedure

### 10.1 Removal Procedure of Indoor Unit

Warning

Be sure to wait for a minimum of 10 minutes after turning off all power supplies before disassembly.

NOTE:Tal	ke C1 front panel for example.	
Steps		Procedure
1. Before	e disassembly	
2. Remov	Remove the screws fixing the display box cover and panel, and then remove the display and display cover box.	display cover display board
3. Remo	ve panel	
	Push out the clasps at both sides of panel to separate the panel and front case, and then remove the panel.	front panel assy

# Procedure Steps 4. Remove filter sub-assy Loosen the clasps on filter sub-assy, push the filter inwards and then pull it upwards to remove it. filter sub-assy 5. Remove electric box cover 2 electric box cover 2 Remove 2 screws on electric box cover 2 and then remove the electric box cover 2. 6. Remove horizontal louver and swing blade Push out the axial bush on horizontal louver, а bend the horizontal louver and pull it outwards to remove it. horizontal louver axial bush Loosen the clasps connecting the swing blade b and bottom case, and then remove the swing blade.


# Steps Procedure 7. Remove front case front case sub-assy Remove the screws connected with front case and bottom case, open the screw cap and then remove the other screw. Loosen the clasp connected with front case bottom case, pull it upwards and then remove the panel sub-assy. 8. Remove electric box sub-assy electric box cover 1 Loosen the clasp connected with the electric а box cover1 and then electric box, and then remove the electric box cover 1. Remove the screws connecting electric box b and bottom case, loosen the clasps, remove the electric box assy screws connecting the erathing wire and evaporator, pull out the indoor room temperature sensor, and then remove the electric box. 9. Remove evaporator pipe clamp Turn over the bottom case, remove the screws а connecting press plate of connecting pipe and bottom case, loosen the clasps between press plate of connection pipe and bottom case, and then remove the press plate of connecting pipe.

Steps	Procedure				
b	Remove the screws between evaporator and moor press plate, loosen the clasps fixing evaporator and bottom case, and then remove the evaporator.	evaporator assy			
10. Remo	ove axial flow blade and motor	motor press plate			
а	Remove the screws connecting the motor press plate and bottom case, and then remove the motor press plate.	1			
b	Take out the cross flow blade and motor, remove the screws fixing the cross flow blade and motor shaft, and then remove the motor.	cross flow blade  fan motor			
С	Take out the shaft cushion block, remove the screws of stepping motor, and then remove the stepping motor.	o-gasket sub-assy of bearing			

### 10.2 Removal Procedure of Outdoor Unit(09K)

Warning

Be sure to wait for a minimum of 10 minutes after turning off all power supplies before disassembly.



# Steps Procedure 3.Remove grille 、 axial flow blade and front panel Remove connection screws between the front grille and the front panel. Then remove the front grille. Remove connection screws connecting the front panel with the chassis and the motor support, and then remove the front panel. Remove the nut fixing the blade and then remove the axial flow blade. axial flow blade panel grille 4.Remove right side plate right side plate Remove connection screws connecting the right side plate with the valve support and the electric box. Then remove the right side plate. 5.Remove electric box subassembly Remove screws fixing electric box cover, and then electric box remove the electric box cover. Cut off the tieline, subassembly pull out all wiring terminals and remove all connection wires, and then separate connection wires and electric box. Remove screws connecting electric box and middle isolation sheet, motor support, and then remove the electric box.


# Steps Procedure 6.Remove 4-way valve assy 4-way valve assy Unscrew the fastening nut of the 4-way valve assy coil and remove the coil. Wrap the 4 way Valve Assy with wet cotton and unsolder the 4 weld spots connecting the 4-way valve assy to take it out.(Note: Refrigerant shouldbe discharged firstly.) Welding process should be as quickly as possible and keep wrapping cotton wet all the time. Be sure not to burn out the lead-out wire of compressor. 7.Remove motor and motor support motor support Remove the 4 tapping screws fixing the motor. Pull out the lead-out wire and remove themotor. Remove the 2 tapping screws fixingthe motor support. Lift motor support to re-move it. motor 8.Remove isolation sheet isolation sheet Remove the screws fixing the isolation sheet and then remove the isolation sheet.

# Steps Procedure 9.Remove valves Remove the 2 screws fixing the gas valve and unsolder the welding point between the gas valve and the air-return pipe to remove the gas valve. Remove the 2 screws fixing the liquid valve and unsolder the welding joint connecting the liquid valve to the Y-type pipe to remove the liquid valve. liquid valve gas valve 10.Remove compressor Remove the foot nuts on the compressor and then remove the compressor. compressor

## 10.3 Removal Procedure of Outdoor Unit(12K)



Be sure to wait for a minimum of 10 minutes after turning off all power supplies before disassembly.




# Steps Procedure 3. Remove grille and front panel 1 Remove connection screws between the front grille and the front panel. Then remove the front grille. Grille 2 Remove connection screws connecting the front panel with the chassis and the motor support, and then remove the front panel. Front panel 4.Remove right side plate Right side plate Remove connection screws connecting the right side plate with the valve support and the electric box. Then remove the right side plate.

Steps	Proced	ure
5.Remov	Remove the nut fixing the blade and then remove the axial flow blade.	Axial flow blade
6.Remov	re reactor sub-assy and electric box assy	Reactor sub-assy
1	Remove the screws of the reactor sub-assy and then remove it.	Reactor sub-assy
2	Remove screws fixing the electric box assy; loosen the wire bundle and unplug the wiring terminals. Then lift the electric box to remove it.	Electric box assy

### Steps Procedure


### 7.Disassemble motor and motor support

Remove the 4 tapping screws fixing the motor. Pull out the lead-out wire and remove the motor. Remove the 2 tapping screws fixing the motor support. Lift motor support to remove it.




### 8.Disassemble 4-way valve assy

Unscrew the fastening nut of the 4-way valve assy coil and remove the coil. Wrap the 4-way valve assy with wet cotton and unsolder the 4 weld spots connecting the 4-way valve assy to take it out.(Note: Refrigerant should be discharged firstly.) Welding process should be as quickly as possible and keep wrapping cotton wet all the time. Be sure not to burn out the lead-out wire of compressor.



### 9.Disassemble capillary sub-assy

Unsolder weld point of capillary sub-assy, valve and outlet pipe of condensator. Then remove the capillary sub-assy. Do not block the capillary when unsoldering it. (Note: before unsoldering, discharge refrigerants completely)



# **Steps Procedure** 10.Disassemble clapboard sub-assy Clapboard sub-assy Loosen the screws of the clapboard sub-assy. The clapboard sub-assy has a hook on the lower side. Lift and pull the clapboard sub-assy to remove. 11.Disassemble compressor Remove the 2 screws fixing the gas valve. Unsolder the welding spot connecting gas valve and air return pipe and remove the gas valve. (Note: it is necessary to warp the gas valve when Liquid valve unsoldering the welding spot.) Remove the 2 screws fixing liquid valve. Unsolder the welding spot connecting liquid valve and remove the liquid valve. Gas valve 2 Remove the 3 footing screws of the compressor Compressor and remove the compressor.

JF00300493

### **GREE ELECTRIC APPLIANCES, INC. OF ZHUHAI**

Add: West Jinji Rd, Qianshan, Zhuhai, Guangdong, China, 519070

Tel: (+86-756) 8522218 Fax: (+86-756) 8669426

E-mail: gree@gree.com.cn www.gree.com

For continuous improvement in the products, Gree reserves the right to modidy the product specification and appearance in this manual without notice and without incurring any obligations.